




Thank You for purchasing this Quality product. It has been engineered for easy assembly yet constructed for durability. Please take the time to read and follow the instructions while assembling.

# ASSEMBLY INSTRUCTION





RUSTIC Media Console

Size : 53" x 18" x 28" H


## List of Part For 1 Set

01		Top Assembly	1
02		Btm Shelf	1
03		Side Panel	2


## List of hardware

a		Flat Washer 1/4" x 16mm	16
b		Spring Washer 1/4"	16
c		JCBC Bolt M 6 x 40mm	16
d		Allen Key M 4	1


### Step 1




### Step 2



### Step 3



### Step 4



Assembly Completed !!..



### Important Notes

- \* Keep all hardware parts out of reach of children.
- \* Nut holding legs on the table can work loose. Check every 6-8 weeks that nuts are tight.
- \* Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

### Notes

- \* Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
  - \* Check to be sure that you have all parts and hardware.
  - \* Remove all wrapping materials including staples & packing straps before you start to assemble.
- Care And Maintenance**
- \* The Touch of a soft cloth is all the maintenance your wood pieces will ever need.
  - \* Never use harsh chemicals or abrasive cleaner as they could mark or destroy finish.