

Premium

PERSONAL SCALE
BÁSCULA PERSONAL



This product is for domestic use only

Use & Care Manual
Important Safeguards

MODEL: PWS103
MODELO: PWS103

Personal Scale

Specifications

Starting weight: 7kg/15.4lb

Capacity: 150kg/300lb

Graduation: 0.1kg/0.2lb

Display: 4 digits LCD

Power: 3V CR2032 lithium battery

Operating temperature: 5-35 degrees Celsius

Unit: kg/lb

Automatic shutdown: 8 seconds

Low voltage display: "Lo"

Error display: "Err"

Overweight display: "O-Ld"

Instructions

Open the battery cover below the scale, turn the switch to the unit of measure you need: left to "kg", center to shut the power off, right to "lb".

Put the scale at ground level, and after the scale shows 0.0 kg/0.0lb, you can step on the scale.

Stand steady in the center of the scale. When the weight value is stable, the weight value is locked.

If you leave the scale and step on the scale again after it locked, you can reweigh.

If you don't leave the scale after it locked, the value remains displayed for 8 seconds before automatic shutdown.

If the scale displays "Lo", the battery is worn off and should be replaced.

Attention:

When not in use, do not put heavy objects on the scale for a long time.

When weighing, you must stand in the middle of the scale.

You must stand steady on the scale.

The scale must not be hit.

Do not use the scale where there is water. Do not wash the scale with water.

The scale has a factory installed battery.

Maintain the scale and your feet dry when weighing.

Báscula Personal

Especificaciones

Peso Inicial: 7 kg / 15.4 lb

Capacidad: 150kg/300lb

Graduación: 0.1kg/0.2lb

Pantalla: 4 dígitos LCD

Potencia: pila de litio CR2032 de 3V

Temperatura de funcionamiento: 5-35 grados Celsius

Unidad: kg/lb

Apagado automático: 8 segundos

Mensaje de bajo voltaje: "Lo"

Mensaje de Error: "Err"

Mensaje de sobrepeso "O-Ld"

Instrucciones

Abra la tapa de la batería en la parte inferior de la báscula, gire el interruptor a la unidad de medida que usted necesita: a la izquierda para "kg", al centro para apagar, a la derecha para "lb".

Coloque la báscula a nivel del suelo, y luego de que muestre 0.0 kg/0.0 lb, usted puede subirse a la báscula. Párese en el centro de la báscula. Cuando el valor del peso mostrado sea estable, el valor del

peso estará bloqueado.

Si se baja de la báscula y se sube de nuevo después de que el peso se haya bloqueado, usted puede volver a pesarse.

Si no se baja de la báscula después de que quede bloqueada, el valor se muestra durante 8 segundos antes de apagarse automáticamente.

Si la báscula muestra el mensaje "Lo", la batería está descargada y debe reemplazarse.

Atención:

Cuando no esté en uso, no coloque objetos pesados sobre la báscula durante mucho tiempo.

Cuando pese, ubíquese en el centro de la báscula.

Usted debe mantenerse inmóvil en la báscula.

No golpee la báscula.

No utilice la báscula donde haya agua. No lave la báscula con agua.

La báscula viene con una batería instalada en la fábrica.

Mantenga la báscula y sus pies secos al pesarse.

Premium

**Manual de uso y cuidado
Precauciones importantes**

Este producto es para uso doméstico únicamente.