





PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.




LOVESOFA




PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



1. SOFA




M6x15 Bolt 24x



Washer Bolt 24x




Allen Key




PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



.TABLE



M6x15 Bolt 12x



Washer Bolt 12x



Allen Key

