
Swivel Glider Recliner

Weight Limit:250Lb/113Kg



Thank you for purchasing



DO NOT RETURN TO THE STORE!

If parts are missing or damaged, we will gladly ship your replacement parts free of charge.



THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY

Limited 1 year Warranty

warrants this product to be free from defects in material and workmanship and agrees to remedy any such defect. This warranty covers one year from the date of original purchase from authorized retailers. This is solely limited to the repair or replacement of defective parts and assembly labor is not included.

This warranty does not apply to any product which has been improperly assembled, subjected to misuse or abuse or which has been altered or repaired in

any way. The warranty does not cover wearing, tearing, fading or splitting of the fabric (where applicable). Liability for consequential damages is excluded to the extent exclusion is permitted by law. This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province.


To obtain warranty service, purchaser must present original bill of sale. Components repaired or replaced are warranted through the remainder of the original warranty period only. The defective components will be repaired or replaced without charge, subject to the terms and conditions described above.

Contact Us!

For help with assembly, identifying parts, product information or to order parts, please contact us:

Read Before Beginning Assembly

- Work in a spacious area and near where the unit will be used, preferably on a carpet, or use a piece of the cardboard packaging to protect your floor and product.
- Make sure all parts are included. Most parts are labeled or stamped on the raw edge.
- Read each step carefully. It is very important that each step of the instructions is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.
- This product may contain small components. Please ensure that they are kept away from small children.
- This product is designed for home use and not intended for commercial use.






This product is packaged in 1 carton



| PARTS LIST | |
|--------------|------------|
| A | B |
| BACK CUSHION | SEAT FRAME |
| X1PC | X1PC |




Step 1

With the help of another person, slide the metal brackets on back cushion (**A**) into the metal glides on seat frame (**B**). Lower back cushion (**A**) onto seat frame (**B**) until it locks into place. Place the fabric flap into position using the velcro strips once back cushion (**A**) has been locked into place.

A

CAUTION: This unit is intended for use only with the products and/or maximum weights indicated. Use with other products and/or products heavier than the maximum weights indicated may result in instability or cause possible injury.



Weight Limit: Recliner: 250 lb / 113 Kg

That's it! You've finished assembling your recliner!

Helpful Hints

- Move your new furniture carefully, with two people lifting and carrying the unit to its new location.
- Your furniture can be disassembled and reassembled to move.
- Dust regularly with a soft, dry cloth to prevent soil build-up. Use a professional cleaning service to clean the fabric.
- Check all bolts, screws and fasteners periodically and tighten them if necessary.
- Some parts have been pre-assembled for this item.
 They are illustrated on this page and available for replacement.

▲ Warnings

- Keep away from heat to avoid glazing, melting or scorching.
- DO NOT leave children unattended on or beside the recliner.
- DO NOT use your recliner as a step stool.
- DO NOT sit on the edge of the seat, armrests or on the backrest as this could make the recliner tip over.
- Read all instructions before use of the recliner.
- Do not use the unit if it is damaged or broken.
- Caution: Adult assembly required.