






Assembly Instructions






We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.












Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.


Parts List

 1 2 pcs	 2 1 pc	 3 2 pcs	 4 2 pcs	 5 2pcs
 6 2 pcs	 7 2 pcs	 8 2 pcs	 9 2 pcs	 10 2 pcs
 11 2 pcs	 12 2 pcs	 13 4pcs		

Hardware List


 A 12PCS	 B 32PCS	 C 32PCS	 D 4PCS	 E 40PCS	 F 24PCS
 G 18PCS	 H 1PCS	 I 40PCS			

1




12PCS

2



12PCS

3




E

12PCS

G

8PCS

4




E

12PCS

G

8PCS


5



B

8PCS


6



B

8PCS



7



B

8PCS

8



X2



D

E


G

4PCS

8PCS

2PCS


9



F

8PCS


10



B

8PCS


11



F

16PCS


12



C


8PCS

13





E

8PCS



14



A

I

12PCS

40PCS

