















ASSEMBLY INSTRUCTIONS
INSTRUCTIONS D'ASSEMBLAGE










TV STAND DARK GREY WOOD 2 DRAWERS 3 SHELVES
MEUBLE TV BOIS GRIS FONCÉ 2 TIROIRS 3 ÉTAGÈRES




						
	φ15x9mm	4x40mm	6x30mm	3x12mm	4x12mm	6x12mm
A 14PCS	B 14PCS	C 26PCS	D 28PCS	E 24PCS	F 10PCS	G 15PCS
						
6x25mm				φ20mm		
H 8PCS	I 1PC	J 2PCS	K 2PCS	L 4PCS		


step 1




180°




step 2




step 3




step 4




step 7




step 8




step 9






step 10




step 11





step 12



x4




step 13




x2


step 14








step 15



step 16



step 17



step 18

