

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help.


PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use. Remove wooden furniture from standing water. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Chair seat		4X	F	Table Top		2X
B	Chair Leg		3X	HW1	Table screw M6*14mm		16X
C	Chair Leg		3X	HW2	Flat washer		64X
D	Chair Leg		1X	HW3	Chair screw M6*20mm		48X
E	Table leg		8X	HW4	Allen key		1X


Owner Manual

Product Dimensions:

Double: 54.33*28.54*29.72IN

Single: 28.74*28.54*29.72IN

Table:22.24*22.24*16.06IN



WARNING

**WEIGHT CAPACITY- 275LBS
DO NOT STAND ON CHAIR**




WARNING

Weight Capacity- 200LBS
Warning: Do not stand on the Table
Warning: Do not over torque bolts


PREPARATION

2


- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help.




STEP1: Side by side inverted seat A, Align the D-leg with the hole position, insert the washer HW2 into the screw HW3 and lock it.



STEP3: Align C-leg with the corresponding holes, insert the washer HW2 into the screw HW3 and lock it.



STEP2: Align the B-leg with the hole position, insert the washer HW2 into the screw HW3 and lock it.




STEP4: Finish


PREPARATION

3


- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help.




STEP1: Inverted seat A



STEP3: Align C-leg with the corresponding holes, insert the washer HW2 into the screw HW3 and lock it.



STEP2: Align B-leg with the corresponding holes, insert the washer HW2 into the screw HW3 and lock it.




STEP4: Finish


PREPARATION

4


- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help.




STEP1: Inverted table top D



STEP3: Align E with the corresponding holes, insert the washer HW2 into the screw HW3 and lock it. same with step 2, finish the other three legs.



STEP2: Align E with the corresponding holes, insert the washer HW2 into the screw HW3 and lock it.



STEP4: Finish