


EGP241064PVB 110V
Installation & Operating Instructions for the
Owner's Installation ,Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

EGP241064PVB 110V

Pendant Lighting




EGP241064PVB 110V

Installation & Operating Instructions for the
Owner's Installation ,Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

PACKAGE CONTENTS




PART	DES CRIPTION	QTY.	PART	DES CRIPTION	QTY.
A	Canopy	1	H	Lamp body	1
B	Mounting bracket	1	I	Rubber washer + 2 replacement	60+2
C	Outlet box screw	2	J	Mounting screw + 2 replacement	60+2
D	Mounting ball	2	K	Glass accent 1 + 1 replacement	32+1
E	Loop	1	L	Glass accent 2 + 1 replacement	28+1
F	6 In. rod	2	M	Glass accent 3 + 1 replacement	24+1
G	12 In. rod	2	N	Quick link	1

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

HARDWARE CONTENTS

AA



Wire
Connector
Qty: 3

! SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

! WARNING

- IMPORTANT: NEVER attempt any work without shutting off the electricity.
- Place the main power switch in the "OFF" position and unscrew the fuse(s), or switch "OFF" the circuit breaker switch(es), that control the power to the fixture or room you are working in.
- Place the wall switch in the "OFF" position. If the fixture to be replaced has a switch or pull chain, place it in the "OFF" position.
- Do not use bulbs with wattage greater than specified on this fixture.
- California Prop. 65: This lighting fixture contains chemicals known to the state of California to cause cancer, birth defects, and/or other reproductive harm. Wash hands after use.

CAUTION

- If you have any doubts about how to install this lighting fixture, or if the fixture fails to operate completely, please contact a licensed electrical contractor.
- All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to obey this instruction could invalidate ETL listing and/or C.S.A. certification of this fixture.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated assembly time: 30 minutes to 1 hour

Tools Required for Assembly (not included): Phillips screwdriver, flathead screwdriver, wire strippers, electrical tape, ladder, safety glasses.


WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS

1. 6 In. rod (F) 12 In. rod (G)


Lamp body (H)

Note: Choose desired hanging length for the lamp body. Assemble the rods to the desired length. Pass the supply wires and the ground wires through the rod assembly. Attach the rod assembly to the lamp body. Hand-tighten until snug.




2. Loop (E) 6 In. rod (F)

Note: Thread the loop to the uppermost rod. Hand-tighten until snug.



3. Canopy (A) Quick link (N) Loop (E)

Note: Connect the loop to the loop on the underside of the canopy by using the quick link. Close the quick link. Pass the supply wires and the ground wire through the quick link and the canopy.




WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS

4. Mounting bracket (B) Outlet box screw (C)

Note: Secure the mounting bracket to the outlet box (not included) with outlet box screws. Tighten until snug.



5. Wire connection guide: Use the wire connectors to connect the wires.

Ground wire:

- **For installation in the United States:** Wrap ground wire from outlet box around ground screw preassembled on mounting bracket (B) no less than 2 in. from wire end. Tighten ground screw. If fixture is supplied with a ground wire, connect to outlet ground wire with a wire connector (AA).
- **For installation in Canada:** If fixture is supplied with ground wire, wrap ground wire around ground screw on mounting bracket (B). Tighten ground screw. Connect fixture ground wire to outlet ground wire with the wire connector (AA).

Supply wires:

- Connect the Neutral (White) supply wire from the outlet box to the Neutral fixture wire (White or Parallel Cord "D" shaped and ribbed).
- Connect the Hot (Black) supply wire from the outlet box to the Hot fixture wire (Black or Parallel Cord round and smooth).

NOTE:

Fixture wires will either be:

- Black and White.
- Parallel Cord SPT-1 lamp wire with one round smooth wire and one "D" shaped ribbed wire.

AA BARE COPPER,
OR GREEN
GROUND
FIXTURE
WIRE

BARE COPPER,
OR GREEN
GROUND
SUPPLY WIRE

BLACK SUPPLY
WIRE

BLACK FIXTURE
WIRE

WHITE SUPPLY
WIRE


WHITE FIXTURE
WIRE

BLACK SUPPLY
WIRE

OR PARALLEL
FIXTURE CORD
(ROUND AND
SMOOTH)

WHITE SUPPLY
WIRE

PARALLEL FIXTURE
CORD ("D" SHAPED
AND RIBBED)



Hard ware Used

AA Wire Connector



x 3


WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS

6. Mounting bracket (B) Canopy (A)

Mounting ball (D)


Not e: Attach the canopy to the mounting bracket.
Secure with mounting balls.



7. Lamp body (H) Glass accent 3 (M)

Rubber washer (I) Mounting screw (J)


Not e: Pass the mounting screws through the rubber washers, then through the hole in the glass accents 3. Thread the mounting screws into the threaded hole on the lamp body and tighten it securely.



8. Lamp body (H) Glass accent 2 (L)

Rubber washer (I) Mounting screw (J)

Not e: Pass the mounting screws through the rubber washers, then through the hole in the glass accents 2. Thread the mounting screws into the threaded hole on the lamp body and tighten it securely.




WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS

9. Lamp body (H) Glass accent 1 (K)

Rubber washer (I) Mounting screw (J)


Note: Pass the mounting screws through the rubber washers, then through the hole in the glass accents 1. Thread the mounting screws into the threaded hole on the lamp body and tighten it securely.



10. Install the correct bulbs (not included) referring to fixture markings and/or labels for maximum wattage.



NOTE: Use four 60W maximum medium base (E26) type "A" or 9W maximum medium base (E26) self-ballasted LED bulb (sold separately).



CARE AND MAINTENANCE

- . Always be certain that electric current is turned off before cleaning this item.
- . Use a soft, moist cloth with mild non-abrasive soap to clean fixture. Never use glass cleaner on fixture, as it will damage the metal finish.
- . All glass shades may be washed in a towel-lined sink with warm water and mild soap. Do not wash shades in an automatic dishwasher.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Fixture does not light.	1. Fixture may be wired incorrectly. 2. Worn or broken bulb.	1. Check wiring. 2. Replace bulb.