



Assembly Manual

Dining Chair



Exploded View



Components List

10 min

Assembly Time



One People



1

Backrest(x1)




2

Seat Pan(x1)



3





Leg(x3)



4

Crossbar(x1)


Components list

A			B			C		
								
Bolt	M8x30	3+1	Bolt	M6x20	12+2	Washer	M6x16	4+1
D			<p>Note: The number after "+" sign indicates the extra piece(s).</p>					
								
Allen wrench	M6	1						

Assembly Instruction


STEP 1

Attach crossbar(4) to rear leg(3) using bolts(B) and Allen wrench(D). Do NOT fully tighten the bolts. Tighten them to about 60% of their capacity. This will allow you slight adjustments during the assembly.



STEP 2



Attach leg (3) to crossbar using bolts(B) and Allen wrench(D). Do NOT fully tighten the bolts. Tighten them to about 60% of their capacity. This will allow you slight adjustments during the assembly.



Assembly Instruction


STEP 3

Attach the frame to the underside of the backrest (1) using bolts (A) and Allen wrench (D).



STEP 4


Turn the chair right side up and place the seat cushion (2) onto the crossbar.



Assembly Instruction


STEP 5

Turn it over again and attach the seat cushion to the frame using washers (C), bolts (B) and Allen wrench (D).



STEP 6

Check all the bolts are tightened before turning the chair right side up.



Assembly Instruction

STEP 7

Assembly is complete. If you find the chair not level, please adjust it by rotating the adjustable feet pads at the ends of the legs.

