





TOOLS:




BOLT INSTALLATION AS BELOW:




Adjust connecting piece direction if condition as illustrated

Insert bolt when Connecting piece under Such condition




BACKPLATE BUCKLE INSTALLATION AS BELOW:


B1.




B2.




1.




2.




3.




4.




5.




6.




7.




8.




9.




10.




11.




12.




13.




14.




15.




16.




17.




18.(X2)




19.(X2)




20.(X2)




21.(X2)



22.



23.



24.

