


INSTRUCTION MANUAL



Thank you for purchasing our product.

Please contact us and Leave ordernumber if you have difficulty with installing or need replacement parts.

Customer service is here to assist you all the time.

Email: support@elyken.com

CONTACT US !

Do Not return this product

Contact our friendly customer service team first for help

①



Email: support@elyken.com

②



Amazon Message

Q: If the parts were missed or damaged when received, what can i do?

A: There are two solutions.

1. Please purchase the missed part from the local store and send the receipt to us on Amazon, we will pay for it.

2. You could contact us on Amazon or by after-sale e-mail and we will reply and solve the problem for you in 24 hours. Our after-sales mailbox is

support@elyken.com, thank you!

General Guidelines:


1. Please read the following instruction carefully and use the product accordingly.
2. Please keep this manual and hand it over when you transfer the product.
3. This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.




Notes:

1. This item is only intended to be used indoors. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The product must be assembled and used in accordance with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
2. It is recommended that assembly is undertaken by at least 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined.
3. If there is/are defective and/or missing part/s after unpacking, please cease assembly immediately and get in contact with us.
4. Please assemble the item in a spacious room and do not place the unwrapped product directly on the ground to avoid damage. It is recommended to wear gloves during the assembly to avoid scratches from any sharp edges.
5. Please do not stand, sit or place heavy items on the wooden boards or other parts before assembly to avoid cracks or distortion of the wooden boards. Cracks or distortion will affect the assembly and normal use.
6. Please match the corresponding board and fitting based on the part number in the manual. If the board does not match with the fitting, please check the pieces as specified in this manual.
7. Please refer to the diagram during assembly. Align all screws with the related pre-drilled holes first and later tighten the screws one by one only after putting all the parts in their correct places.
8. Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
9. Do not expose product to direct sunlight exposure or rain; and do not put it in a humid place. Failure to do so may accelerate the distortion, discoloration or cause fissures. Never touch with sharp objects or corrosive chemicals, which may damage the surface of the item.
10. For daily care, please clean with a damp cloth then immediately wipe dry.

Warnings:


1. It is strictly prohibited to sit or stand on the product.
 2. Please put this item on a flat ground.
 3. Don't use an electric drill to assemble this item.
 4. It is not intended for use by children under 3 years of age. Children must be under adult supervision to use the product.
 5. It is forbidden children to climb or play on the product to avoid serious body injury caused by the toppling.
 6. During the assembly process, keep any small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- Ÿ To avoid the potential dangers of suffocation, please keep all parts and packaging (films, plastic bags and foam, etc.) away from babies and children.




					
Ax47	Bx47	Cx24	Dx 27	Ex32	Fx4
					
Gx3	Hx8	Ix1	Jx8	CLx3	CRx3
					
DLx3	DRx3				

How to use furniture connector cam lock screw and fitting?

Eccentric wheel(A)




Dowel(B)




1

Use screwdriver to attach
dowel into pre-inserted nut




2

Step 1 completed




3

Attach dowel into hole on fitting board




4

Put eccentric wheel (cam lock fitting) into hole




5

Tighten: Turn the eccentric wheel clockwise
Loosen: Turn it anticlockwise




Step 1

	Ax2
	Bx2
	Cx2




Step 2


	Cx6
	Dx6




Step 3



	Bx2
	Ex6
	CRx3





Step 4



	Ax2
	Bx2
	Cx2



Step 5

	Cx6
	Dx6



Step 6


	Bx2
	Ex4
	CLx2



Step 7



Ax2




Step 8




Ax2




Cx2



Step 9




Step 10



	Cx4
	Fx4


Step 11

	Ax4
	Bx4




Step 12

	Bx8
---	-----




Step 13

 Ax8




Step 14


 Bx8



Step 15




Step 16




Step 17

	Ax4
	Bx4
	Cx4



Step 18


	Ex2
	Ix1
	Jx8



Step 19




Dx15




x3

Step 20




x3

Step 21



Step 22



Step 23

