


Lighting Tree Instruction

Product introduction:



LED lighting tree is also called LED landscape lighting tree or LED artificial tree. It has the advantages of energy saving, high brightness, colorful, long service life, vivid model. As a kind of artificial plant light, it puts beautification, greening, lighting together. Its unique, elegant and magnificent modelling, beautiful gesture, and make it more adaptable to the place such as city-lighting project, scenic area, hotel, cultural square, community activities in public places, coastal landscape and so on. Tree lights will satisfy people's desire everywhere. During the daylight, it is the artificial plant trees, at night it will give people a totally different lighting beauty. Return to the nature, walk into nature, it not only beautifies the environment but also adds a beautiful scenery line. Now, more and more lighting trees are applied to city-lighting, landscape lighting, home decor and other places. In particular, when festival is coming, it will become an indispensable scenery line.

Direction for use:



1. Take out the product from package carefully.



2. Insert tree trunk part 2 into base and rotate until fixed. Insert tree trunk part 1 into part 2.



3. Fix base with ground stakes(when using outdoor); Connect the cable with transformer then plug into power outlet.



The tree can be shaped by bending and arranging the branches into desired position to give it a natural appearance!

- Power supply: 24V adaptor, IP44 rainproof
- Input: 120V AC 50/60Hz
- Output: 24V DC 6W

IMPORTANT SAFETY INSTRUCTIONS

When using outdoors, please install to a covered weather proof GFCI electrical outlet. Make sure the adaptor and cord are assembled correctly and secured tightly to prevent from water.

1. Please read and follow all instructions and warnings on the instructions and product carefully before using.
2. Retain the instruction for future reference.
3. This product should be used only as intended.
4. For indoor/ outdoor use.
5. If using outdoors, connecting the product to a Ground Fault Circuit Interrupting (GFCI) receptacle.
6. Do Not mount or place near gas, electric heaters, fireplaces, candles or other similar sources of heat.
7. Do not secure the wires with staples, nails, or anything sharp which may cut the wire and insulation.
8. This is an electric product, not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where children can reach it.
9. Avoid the product and extension cords being caught by doors or windows, which may damage the wire and insulation.

TROUBLESHOOTING

1. Whole tree doesn't light up:

First, please check if the components have been connected normally.

Second, check the plug cord has been connected properly to the adapter in right position of male and female connection.

Last, check the adapter works or not by switching another same adapter. If no replacement, please follow step 3 to contact seller.

2. One or more of the branches doesn't light up:

Please check each bulb on the unlighted branch has been well welded by toughing slightly, or bending the branch slightly. If it doesn't work please follow step 3.

3. Any problem not mentioned above or unsolved:

Please contact us at service@ehomeinc.com for assistance.

WARRANTY

Lightshare guarantees that this product is free of defect in material and workmanship, and provides a one-year limited hardware warranty for the product commencing from the date of purchase. Please keep your receipt for proof of purchase. This product is designed for light or decoration usage only. Using this device in any other capacity voids the warranty.

The warranty offered covers normal use. Defect or damage that result from improper operation, storage, misuse or abuse, accident or neglect, which are not the fault of Lightshare, are excluded from warranty coverage.

FAQ:

Q:How many times can each branch be bent?

A:Please do not bend each branch more than 5 times as high-frequency bend will loose the connection between branches and also affect the appearance. If there is a loose, you are advised to bind it with an electrical tape in similar color of branches.

Q:If one of lights doesn't work, will it affect the run of the others?

A:The others will not be affected and could work normally.

Q:Is the power supply safe for running?

A:The voltage output of the power adapter is 24V. This product runs steadily and safely under the correct voltage.

Distributed by E HOME INTERNATIONAL INC.
725 Old Norcross Rd. Ste D, Lawrenceville, GA 30046

Customer Service Line: (888) 997-9468
www.ehomeinc.com
service@ehomeinc.com

