


Assembly Instructions

6 Chest Of Drawer White Wide




IMPORTANT— RETAIN FOR FUTURE REFERENCE

PRODUCT PARTS LIST




Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty
A	M6*35mm		57
B	Ø15*10mm		57
C	Ø5.8*30mm		24
D	M6*30mm		2
E	M4*35mm		35
F	M3.5*12mm		69
G	M3*16mm		16
H			16


Ref	Dimensions	Visual	Qty
J	M68*32mm		2
K	M4*12mm		2
CL	300mm		6
CR	300mm		6
DL	300mm		6
DR	300mm		6

1


x6



2




3




x6

4




x6


7




8




9




10





11




12









15








17




WALL



18





WARNING



Children have died from furniture tipover.

To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors or shelves.
- NEVER open more than one drawer at a time.

This is a permanent label.



Do not remove!