













Assembly Instructions








Caution : You must read this before you proceed

KITCHEN CART



























Parts List

| Label | Picture | Description | QTY |
|-------|---|-------------------|-----|
| A |  | Left Side Panel | 1 |
| B |  | Hanger Rail | 2 |
| C |  | Towel Rail | 2 |
| D |  | Cross Bar | 1 |
| E |  | Right Hanger Rail | 1 |
| F |  | Left Hanger Rail | 1 |
| G |  | Right Side Panel | 1 |
| H |  | Partition | 1 |
| I |  | Shelf | 1 |
| J |  | Stretcher | 1 |
| K |  | Bottom Panel | 1 |

| | | | |
|---|---|------------------|---|
| L |  | Stretcher | 2 |
| M |  | Back Panel | 2 |
| N |  | Top Panel | 1 |
| O |  | Right Door Panel | 1 |
| P |  | Left Door Panel | 1 |
| Q |  | Shelf | 2 |
| R |  | Cross Bar | 1 |

Hardware

| Label | Picture | Description | QTY |
|-------|---|--------------------|-----|
| ① |  | Screw (M5x50mm) | 7 |
| ② |  | Allen Key | 1 |
| ③ |  | Cam Bolt | 17 |
| ④ |  | Cam Lock | 17 |
| ⑤ |  | Dowel | 31 |
| ⑥ |  | Bolt (M6x25mm) | 10 |
| ⑦ |  | Magnet | 2 |


| | | | |
|---|---|-------------------------------|----|
| ⑧ |  | Screw (M3x15mm) | 5 |
| ⑨ |  | Bolt Nut | 9 |
| ⑩ |  | Bolt (M6x65mm) | 9 |
| ⑪ |  | Wheel (with brake) | 2 |
| ⑫ |  | Wheel | 2 |
| ⑬ |  | Wrench | 1 |
| ⑭ |  | Screw (M4x25mm) | 3 |
| ⑮ |  | Bracket | 2 |
| ⑯ |  | Hinge | 4 |
| ⑰ |  | Screw (M3x12mm) | 3 |
| ⑱ |  | Handle | 2 |
| ⑲ |  | Screw (M4x20mm) | 5 |
| ⑳ |  | Pin | 9 |
| ㉑ |  | Buckle | 4 |
| ㉒ |  | Screw (M3x15mm) | 5 |
| ㉓ |  | Screw (M4x14mm) | 25 |
| ㉔ |  | Screwdriver (Not provided) | 1 |

This Kitchen Cart has multiple parts and may require up to 60 minutes to assemble.

To give you an overview of the Kitchen Cart parts, the above picture is to help you put the various parts into perspective.


Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.


Step 2



2.1) Connect Hanger Rail(B) and Towel Rail(C).

2.2) Attach Left Side Panel(A) to B using Screw(①) with Allen Key(②) as shown.


Step 3



3.1) Connect Towel Rail(C), Right Hanger Rail(E) and Left Hanger Rail(F). Attach Cross Bar(D) to the Dowel(⑤) and Cam Bolt(③) on Left Hanger Rail(F) and Right Hanger Rail(E), insert Cam Lock(④) into Cross Bar(D) using Screwdriver(②④) as shown.

3.2) Attach Right Side Panel(G) to Dowel(⑤) on Right Hanger Rail(E) and Left Hanger Rail(F), insert the Nut(⑨) into Right Hanger Rail(E) and Left Hanger Rail(F), then using Bolt(⑩) and Screw(①) with Allen Key(②) as shown.

Step 4




4.1) Attach Shelf(I) to Dowel(⑤) on Partition(H), insert Nut(⑨) into Partition(H), then using Bolt(⑩) with Allen Key(②) as shown.

4.2) Insert Cam Bolt(③) and Dowel(⑤) into Stretcher(L) with Screwdriver(②④)

Attach Cross Bar(R) to Stretcher(L) using Cam Lock(④) with Screwdriver(②④)


4.3) Attach Cross Bar(R) and Stretcher(L) to Dowel(⑤) on Bottom Shelf(K) using Bolts(⑥) with Allen Key(②) as shown.

Step 5



Attach Shelf(I) and Bottom Panel(K) to Dowel(⑤) and Cam Bolt(③) on Right Side Panel(G), insert Cam Lock(④) into Shelf (I) with Screwdriver(②④), insert Nut(⑨) into Bottom Panel(K) using Bolt(⑩) with Allen Key(②) as shown.


Step 6



6.1) Attach Magnet(⑦) to the Stretcher(J) using Screw(⑧) with Screwdriver(②④).


6.2) Attach Stretcher(J) to Right Side Panel(G) with Cam Bolt(③), insert Cam Lock(④) into Stretches(J) with Screwdriver(②④). Attach Shelf(I) and Bottom Panel(K) to Dowel(⑤) on Left Side Panel (A), insert Cam Bolt(③) into Shelf (I) and Stretches(J) using Cam Lock (④) with Screwdriver(②④), insert Bolt Nut(⑨) into Bottom Panel(K) using Bolt(⑩) with Allen Key(②) as shown.

Step 7



Attach Wheel with brake(⑪) and Wheel(⑫) to the Left Side Panel(A) and Right Side Panel(G) with Wrench(⑬).

Step 8




8.1) Insert the Cam Bolt(③) into Top Panel(N) with Screwdriver(②④).

8.2) Insert the Back Panel(M) by sliding in the panel into the grooving as shown.


Attach the Top Panel (N) to Dowel(⑤) on Left Side Panel(A) and Right Side Panel(G) and Partition(H), insert Cam Lock(④) with Screwdriver(②④).

Step 9



Attach Stretcher(J) to the Top Panel(N) using Screw(⑭) with Screwdriver(②④) as shown.

Step 10




Attach Bracket(15) to Right Door Panel(O) using Screw(17) with Screwdriver(24).

Attach Handle(18) to Right Door Panel(O) using Screw(19) with Screwdriver(24).

Attach Hinge (16) to Right Door Panel(O) using Screw(23) with Screwdriver(24).

Repeat the steps above to install the Left Door Panel(P).

Step 11




Attach Right Door Panel(O) to Right Side Panel(G) using Screw(23) with Screwdriver(24).

Repeat the step to Attach Left Door Panel(P) to Left Side Panel(A).

Insert Pin(20) into Left Side Panel(A),Right Side Panel(G) and Partition(H), then put the Panel(Q) on it.

Step 11




Attach the Buckle(21) to the Back Panel(M) using Screw(22) with Screwdriver(24).

Make sure the whole product is stable.

Step 12


Attention: If the doors may shift or sag after assembly, please adjust the hinges according to below instruction.



Vertically adjustment

Slightly adjust the screws position on side panels.

When the doors are flush, lock the middle screws on hinges.



Horizontally adjustment

Slightly adjust the screws position on doors.

When the doors are flush, lock the middle screws on hinges.

Care & Maintenance



- Do not put hot items directly on furniture surface



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only .



- Not for commercial use. For residential use only .



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth .