


ASSEMBLY INSTRUCTIONS


DINING TABLE



WF305830


IMPORTANT NOTE:

- PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP.




CARTON CONTENT:

WF305830 :




1 x 2




2 x 2




3 x 1




4 x 2



5 x 2



6 x 2



7 x 1


TABLE PART LISTS

NO.	DESCRIPTION	SKETCH	QTY
1	TABLE LEG (R)		2 PCS
2	TABLE LEG (L)		2 PCS
3	MIDDLE BAR		1 PC
4	TABLE LEG DECO		2 PCS
5	TABLE LEG BOTTOM		2 PCS
6	INNER APRON		2 PCS
7	TABLE TOP		1 PC

TABLE HARDWARE LISTS

NO.	DESCRIPTION	SKETCH	QTY
A	JCBC BOLT M6 x 45mm		12 PCS
B	JCBC BOLT M6 x 60mm		2 PCS
C	SPRING WASHER 1/4"		14 PCS
D	WOOD DOWEL M10 x 30mm		12 PCS
E	WOOD DOWEL M8 x 30mm		8 PCS
F	ADJUSTER M6 x 23mm		4 PCS
G	ALLEN KEY M4		1 PC
H	C/B SCREW M4 x 50mm		8 PCS




STEP 1



x 2



STEP 2



A x 8



C x 8






G x 1



F x 4

STEP 3

• Tighten first step 3, then continue with step 2



B x 2




C x 2



G x 1





D x 4



E x 8

STEP 4



A x 4




C x 4




G x 1

STEP 5




STEP 6



WOOD DOWEL
M10 x 30mm
D x 4

STEP 7



C/B SCREW
M4 x 50mm
H x 8

ASSEMBLY
COMPLETE !

