


Hand Control Instruction

Diagram



Model No. : LN-605DT-8JR

Operation instructions

First of all, check if local voltage is consistent with the transformer power supply, If available, then plug in, to set up an electric circuit.

The hand controller has a Type-C port on the top, which can easily charge the phone and output DC 5V 1A.

1. The product needs DC 29V power supply, and the small people will light up after connecting the power supply.



2. Back button: Turn on or off the back vibration massage.



3. Lumbar button: Turn on or off the lumbar vibration massage.



4. Thigh button: Turn on or off the thigh vibration massage.



5. Leg button: Turn on or off the leg vibration massage.



6. Mode button: Press the button to select mode M1, M2 or M3.







7. Vibration strength button: Press the button to adjust the vibration strength of the vibration motor.



8. Time button: Press the Button to adjust the timing time of 15 minutes, 30 minutes or 60 minutes.



9. Automatic Mode button: Press the button to open the automatic mode.

10.  Heating button: Press the button to turn the heating function on or off.
11.  Power button: Press the power button to activate the vibration motor.
12.  Linear actuator extension button: Long press this button, the linear actuator will extend.
13.  Linear actuator recall key: Press this key long and the linear actuator will be recalled.