



INSTALLATION INSTRUCTIONS FOR SMALL TRAIN STORAGE RACK




Step1: Install the side plate of the small locomotive with bookshelf cross nuts on both sides of the lower cover of the small locomotive, and tighten them with a plastic screwdriver.




Step2: Assemble the round head of the small locomotive with the assembled side plate of the small locomotive, and tighten it with a plastic screwdriver.




Step3: Take out the side panel of the storage shelf.




Step4: Use the bookshelf Phillips nut to fix the storage rack partition to the side panel of the storage rack and tighten it with a plastic screwdriver.




Step5: Take out the other storage rack side panel and install it on the other side of the storage rack partition, and tighten it with a plastic screwdriver.




Step6: Fix the storage rack partitions to the side panels of the storage rack with bookshelf Phillips nuts in order, and tighten them with a plastic screwdriver.




Step7: Repeat the previous step again, and install another storage rack side plate to the other side of the storage rack partition.




Step8: Fix the storage rack partitions to the side panels of the new storage rack with bookshelf Phillips nuts in order, and tighten them with a plastic screwdriver.




Step9: The small train door panel, with the smooth side facing outwards, is assembled between the two storage shelf partitions, without a nut, and is inserted into the corresponding small hole of the storage shelf partition.




Step10: Assemble the last side panel of the storage rack to the other side, and tighten with a plastic screwdriver.




Step11: After installing the side panels, use the same installation steps to install the small train doors and windows on the opposite side of the small train door panels. No nuts are required, just insert the corresponding small holes.



Step12: Check whether all the nuts are tightened, and after checking, assemble the small locomotive on the side with the assembled storage rack.




Step13: After assembling the small locomotive, use the small train chimney to install the top cover of the small locomotive on the top of the assembled small locomotive.




Step14: Put on the large/small storage box and stick a sticker to complete the installation.


Accessories:




Small locomotive side panel*2




Small locomotive lower cover*1




Side panel of storage rack*4




Small storage box *8




Big storage box *2




Little train chimney *1



Little locomotive top cover*1




Sticker *1



Windows and doors *3




Bookshelf cross nut*60




Storage rack partition *12



Plastic screwdriver*1



Small train door panel*3



Small train round head *1

ADULT ASSEMBLY REQUIRED.

- Keep these instructions for future reference.
- This product is intended for indoor, outdoor, family, domestic use only.
- Place this product on level ground and at least 6.6' away from a fence, building, overhead branches, laundry lines or electrical wires. This product should be placed away from furniture that could cause injury if a fall occurs.
- Ensure the installation area is ventilated.
- Do not use the product if it is damaged or defective. If it is damaged or defective, please contact a qualified technician.
- Check that all parts are assembled well and are stable before use. Defective parts must be changed immediately as they can impair the function and the safety of the product.
- When temperatures fall below freezing (0°C/32°F), outdoor use of this product is not recommended. In extreme cold, plastic materials lose resilience and may become brittle and crack with impact. Store product in a warmer, protected place.
- Keep away from fire or any source of ignition.
- Packing materials are not toys, keep them away from children.
- Instruct children on proper use of this product: only after properly assembled and installed, and not in a manner other than intended.
- Dress children appropriately: do not allow children to wear loose-fitting clothing including ponchos, scarves and garments with drawstrings. Well-fitting shoes must be worn at all times.
- Avoid placing equipment in direct sunlight as hot surfaces could cause serious burns.
- Provide adult supervision at all times.
- Using age is 1-8 years old.