

Farmhouse Executive Desk

ASSEMBLY, CARE & USE INSTRUCTIONS





THANK YOU

We appreciate the trust to purchase our Farmhouse Executive DESK. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing us!




PACKAGE CONTENTS








x2








x3









Hardware List


A		Ø8x30mm	Wood dowel	38+1 PCS
B		Ø6x33.5mm	Cam bolt	51+1 PCS
C		Ø15x 9.5mm	Cam lock	51+1 PCS
D			Sticker	51+1 PCS
E		Ø8x5x18mm	Shelf support pin	4 PCS
F			Connector	24 PCS
G		M6x12mm	Bolt	48 PCS
H			Back buckle	8 PCS
I		Ø3x16mm	Flat-head screw	8 PCS
J		M 4	Hex key	1 PCS
K		ø6x48mm	Screw	8 PCS
L			Handle	6 PCS
M		ø4x22mm	Handle bolt	12 PCS
N		ø6x30mm	Wood dowel	1 PCS
O		ø35mm	Hinge	2 PCS
P		ø4x14mm	Screw	12+1 PCS
Q		ø4x30mm	Screw	22+1 PCS
R		L350mm	Drawer slider	5 PCS
S		ø3.5x12mm	Screw	62+2 PCS
T			Power socket	1 PCS
U			Drawer lock	1 PCS
V		22#	Wrench	1 PCS





Philips head screwdriver required for assembly
(not included)

Step 1



B
B
S
S
S
2
R-CL
S
S
S
CL
R-CL



B x2



R-CLx1



S x3

Step 2



B
B
S
S
S
S
S
S
S
S
S
5
R-CR
R-CR
R-CR
S
S
S
CR
R-CR



B x2



R-CRx3



S x9


Step 3




























Step 4



B
B
S
S
S
S
S
S
S
S
S
4
R-CL
R-CL
R-CL



S
S
S
CL
R-CL



180°



B
B
S
S
S
4
R-CR


S
S
S
CR
R-CR



B x4



R-CLx3



R-CRx1



S x12


Step 5















Step 6








Step 7
















Step 8
















Step 9



















Step 10



















x2

Step 11










x2

Step 12













Step 13













Step 14













Step 15










Step 16














Step 17




















Step 18











x3


Step 19














x3


Step 20











Step 21











B x5


C x5


L x1



M x2



U x1



N x1


V x1


Step 22











Step 23


















Step 24













x3

Step 25













Step 26













Step 27







Step 28





O x2




P x4




L x1




M x2





Step 29






Step 30






To adjust the vertical height.
Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.
Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".



To adjust side ways.
Turning the screw "C" on BOTH hinges on each door.

Step 31

