

Assembly Instructions


Caution : You must read this before you proceed

Care & Maintenance





- ⊘  ● Not for commercial use. For residential use only.
- ✓  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  ● Do not put hot items directly on furniture surface.
- ⊘  ● Do not clean furniture with harsh cleansers or polish.
- ⊘  ● Do not place furniture under direct sunlight.
- ⊘  ● Do not place furniture near heating or cooling vents.
- ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
- ⊘  ● Do not place furniture outside . For indoor use only.
- ⊘  ● Stains may be removed with mild soap solution and damp cloth.
- ⊘  ● Children should not climb or jump on the furniture.
- ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Sets often ship in multiple boxes and may arrive a day or two apart.



Dining Table



Parts List

Label	Picture	Description	QTY
A		Table Top	2
B		Fixed wood	2
C		Connection board	2
D		Foot bucket	2


Hardware

Label	Picture	Description	QTY
①		Bolt (M8*32mm)	17
②		Bolt (M8*57mm)	13
③		Spring Washer (M8)	30
④		Flat Washer (M8)	30
⑤		5mm Allen Wrench	1


Assembly Preparation

Before
Beginning
Assembly:

N771P452677:



N771P452678:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Dining Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Please put the two panels (A) together as shown.
Place all the parts on a clean, non-marring surface.

Step 2




As shown in the picture above, you should place the bottom of the Table Top (A) facing up. Secure the Fixing wood (B) using the Bolts (②) + Spring washers (③) + Flat washers (④) and the Allen Wrench (⑤).

Step 3




As shown in the figure: Please fix the Connection board (C) and the Foot bucket (D) using Bolts (①) + Spring washers (③) + Flat washers (④) and an Allen wrench (⑤).

Step 4



As shown in the figure: Please fix the Table Top (A) and the Connection board (C) using Bolts (①) + Spring washers (③) + Flat washers (④) and an Allen wrench(⑤).

Step 5



Your Dining Table is ready for use.
This Dining Table should only be used on a flat, level surface.