
Assembly Instructions



General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary mav not include every detail of al vaiaions and considered steps. Please contact us when futher information and help are needed.

Notes

- This item is only intended to be used indoors. Personal iniury and/or damage to product may occurif products are used outside oftheir intended purposes and/orif products have been changed'modified from their original design. The product must be assembled and used in accordance with the provisions ofthe manual. These ler does not assume anv resoonsiblty or liablty with resoect to any damage caused by incorrect assemblv or moroper use.
- It is recommended that assembly is undertaken by at least 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outined.
- If there is/are defective and/or missing part/s after unpacking, please cease assembly immediately and get in contact with us.
- Please assemble the item in a spacious room and do not place the unwraped product directly on the ground to avoid damage. It is recommended to wear gloves during the assembly to avoid scratches from any sharp edges.
- Please do not stand, sit or place heavy items on the wooden boards or other parts before assembly to avoid cracks or distortion of the wooden board. Cracks or distortion will affect the assembly and normal use.
- Please match the corresponding board and fiting based on the part number in the manual.If the board does not match with the fiting, please check the pieces as specified in this manual.
- Please refer to the diagram during assembly. Align all screws with the related pre-drilled holes first and later tighten the screws one by one only after puting all the parts in their correct places.
- Please note that each type of screw has a spare screw.
- Periodically inspect screw tightness while the product is in use. lf necessary, retighten to ensure structural integrity.
- Do not expose product to direct sunight or rain; and do not put it in a humid place. Failure to do so may accelerate the distorion,discoloraion or cause fissures.
  Never touch with sharp objects or corrosive chemicals, which may damage the surface of the item.
- For daily care, please clean with a damp cloth, then immediately wipe dry.

Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.



- Identify, sort and count the parts before attempting assembly.

- Compression dowels are lightly tapped in with a hammer.



- Slides are labeled with an R (right) and L (left) for proper placement.



- Make sure to always face the point on the top of the Cam Lock towards the outer edge.

- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.



-Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.




- Do NOT use harsh chemicals or abrasive cleaners on this item.




- Never push, pull, or drag your furniture.


EXPLODED




EXPLODED




① x1PC




② x1PC




③ x1PC




④ x1PC




⑤ x1PC




⑥ x1PC




⑦ x1PC




⑧ x1PC




⑨ x1PC




⑩ x1PC



⑪ x2PCS



⑫ x1PC




⑬ x1PC

HOJA PARTE




A×21+2PCS




B×21+2PCS



C×14+1PCS




D×21+2PCS




F×1PC




G×2PCS




H×4PCS




I×4PCS




J×4PCS



K×1PC



L×4PCS



M×2PCS




N×4PCS




O×2PCS



P×2PCS




Qx8PCS




Rx8PCS




Sx4PCS





STEP1




STEP2










STEP3










STEP4









STEP5







STEP6




STEP7







STEP8

Please unfold component
7 to both sides





STEP9







STEP10







STEP11



F×1PC


G×2PCS




STEP12



B×7PCS



STEP13




Q×8PCS




R×8PCS


STEP14




D×21PCS




STEP15




H×4PCS




STEP16




O×2PCS




P×2PCS




STEP17




M×2PCS




N×4PCS




STEP18




I×2PCS





STEP19






STEP20







Please align the protruding part of the door panel pivot with the hole of component 1 and insert it, note: the magnetic contact iron plate is above.

STEP21










Please hold down the protruding part of the door panel pivot and align it with the hole of component 5 to insert it.

STEP22









Please first mark the hole spacing on the wall with a pen and drill the holes, then embed accessory R into the wall, and finally fix component 10 to the wall with accessory K.

STEP23

