

ASSEMBLY INSTRUCTIONS

COFFEE TABLE

ASSEMBLY

30 MINUTES

2-Person

REQUIREMENTS

Assembly Time

Assembly

Thank you for purchasing our product!


Please refer and use this assembly instruction to assemble the product.

Contact our customer service department in case there are any missing or damage parts or hardware.

We appreciate your business!

ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are complete before you start assembling.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.



SAFETY PRECAUTION:

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY:

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Please check all of the parts and quantities are included before assembly. Contact customer service for missing parts.
4. Identify all of the parts, hardware and quantities required for each step.
5. During assembly, do not over-tighten any fittings as this may cause damage.
6. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
7. Always place the product on a flat surface.
8. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE






- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.
- Do not drag and/or pull the furniture.

This product is for indoor and household use only - not for commercial use.


ASSEMBLY INSTRUCTIONS

COFFEE TABLE

PARTS & HARDWARE LISTS


A		Top Shelf	1PC	D		Bolt	16PCS
B		Bottom Shelf	1PC	E		Allen Key	1PC
C		Leg	4PCS				

STEP 1



Place Top Shelf (A) vertically as shown. Install 3 x Legs (C) first. Use Allen Key (E) to drive Bolt (D) to fasten Leg to Top Shelf. Do not tighten Bolt (D) completely at this time.

STEP 2



Install Bottom Shelf (B). Use Allen Key (E) to drive Bolt (D) to fasten Bottom Shelf to the 3 Legs. Do not tighten Bolt (D) completely at this time.

STEP 3

Install the remaining 4th Leg to the Top and Bottom Shelf. Use Allen Key (E) to drive Bolt (D) to fasten Leg to the shelves. Tighten ALL THE BOLTS when they are all in place.

Place the Table upright. The assembly of the table is complete.

