






























# ASSEMBLY INSTRUCTION

A  1 pc	B  1 pc	C  1 pc	D  1 pc	E  3 pcs
F  1 pc	G  2 pcs	H  2 pcs	I  2 pcs	J  4 pcs
K  1 pc	L  4 pcs	1  12 pcs	2  12 pcs	3  12 pcs
4  4 pcs	5  8 pcs	6  8 pcs	7  4 pcs	8  8 pcs
9  48 pcs	10  16 pcs	11  16 pcs	12  1 pc	

### Step 1




### Step 2





Proper orientation of CAM LOCK


### Step 3




### Step 4




### Step 5




### Step 6




### Step 7




### Step 8




Step 9




Step 10




Step 11




Step 12



### Step 13




### Step 14




**To adjust the vertical height.**  
Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.

### Step 15



**To adjust depth.**  
Loosen screw "B" and adjust door, if the door cannot be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C"

### Step 16



**To adjust side ways.**  
Turning the screw "C" on BOTH hinges on each door.