Champagne Gold Snowman



Illustrated assembly guide

MODEL KS3562

Finished dimensions
Heights: 47.64 in

Keep the power disconnected while joining the frame and light connections. Use the supplied power source for your item.

Before you begin

Arrange the components on a clean surface. Lower body panels, upper body, twig arms, hat, LED cords, adaptor, zip ties and stakes.



Have scissors ready when zip ties are used. Cut only excess tie ends; keep scissors clear of the light wires.

Assembly sequence


Follow the numbered steps. Check each frame and cord connection before applying power.

1 Build the lower body



Connect the two lower body panels at the bottom and zip-tie the sides. Trim excess tie ends clear of wires.

2 Fit the upper body



Feed the upper body LED cord down into the lower body, then fit the upper and lower frame sections together.

3 Secure the body and lights



Zip-tie the body sections together. Join the matching LED cord light connections.

4 Fit the twig arms



Attach the twig-style arms to the matching positions on the body.

Assembly sequence

Follow the numbered steps. Check each frame and cord connection before applying power.

5 Add the hat



Place the top LED lights into the hat area, then attach the hat to the snowman.

6 Secure and illuminate



Use the included ground stakes outdoors if needed. Check the connections, connect the supplied adaptor, and test the lights.

Warranty?
Troubleshooting?

Scan the QR code for
instructions, support, & registration.

XProductSupport.com/product/KS3562

Instructions, support & warranty

Scan the mini card or click below to:

Watch the instructional video
Create a support ticket
Register your item for warranty

XProductSupport.com/product/KS3562