

Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damaged parts or hardware.



We appreciate your business!

ASSEMBLY REQUIREMENT


2-Person Assembly

20 Minutes Assembly Time (Approximate)

Tools Required: **Allen Wrench (provided)**

Phillips Screwdriver (not provided)

Flat Screwdriver (not provided)



ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are complete before you start assembling.
3. Place all components on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

SAFETY PRECAUTION

1. **KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.**
2. **DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.**

TIPS FOR ASSEMBLY

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior and finish of the furniture.
3. Please check all of the parts and quantities are included before assembly. Contact customer service for missing parts.
4. Identify all of the parts, hardware and quantities required for each step.
5. During assembly, do not over-tighten any fittings as this may cause damage.
6. **DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.**
7. Always place the product on a flat surface.
8. Do not sit or stand on the partially assembled product, only use the product for which it is intended.



CARE AND USE

- Recommended for indoor use only.
- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material. Glass cleaner may be used for cleaning.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Do not allow any kind of liquid to remain on your furniture. Absorption can cause the surface to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the surface.
- Do not drag and/or pull the furniture.

ASSEMBLY INSTRUCTIONS



- RECOMMENDED FOR INDOOR USE ONLY.
- SUPPORTS UP TO 45LBS.
- DO NOT STAND ON ANY PART OF THIS DESK.
- DO NOT USE THE DESK UNLESS ALL BOLTS AND SCREWS ARE TIGHT.
- AT LEAST EVERY SIX MONTHS CHECK ALL BOLTS AND SCREWS TO BE SURE THEY ARE TIGHT.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USING THE PRODUCT UNTIL REPAIRS ARE MADE WITH FACTORY-AUTHORIZED PARTS.
- FAILURE TO FOLLOW THESE WARNINGS CAN RESULT IN SERIOUS INJURY.



Attach the shelf bottom (A) to the frame (D) using Wooden Dowels (1) and Screws (2) as shown.




PARTS CHECKLIST

- | | | | | | |
|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 |
|  |  |  |  |  |  |
| ④ Wooden Dowels | ⑥ Drawer Screws | Allen Wrench | ⑧ Screws | ⑧ Colored Covers | ④ Foot Pads |


ASSEMBLY INSTRUCTIONS

2



Attach the legs to the Glass Top (H) using Screws (4) on the bottom panel of the legs as shown. Cover the screws with Colored Covers (5). Make sure you lay the glass on a soft surface before assembling.

3



With another person, slide the shelf inbetween the panels on the legs. Lock into place using screws (4). Cover the screws with Colored Covers (5). Attach the Foot Pads (6) to the bottom of the legs as shown.



PARTS CHECKLIST

1	2	3	4	5	6
					
4 Wooden Dowels	6 Drawer Screws	Allen Wrench	8 Screws	8 Colored Covers	4 Foot Pads