
Instruction Manual

Table Lamp



Overview




Assembly Instruction

1)Pull out the power cord until Socket Assembly reaches Lamp base 2)Rotate Socket Assembly counter-clockwise by two turns

3)Screw Socket Assembly onto Lamp base

4)Install Bulb, then put Lamp shade onto Harp and tighten it with finial



Product Specifications

Input voltage120VRated power100W MAXLamp socketE26Cord Length5ft.

Product Packaging

Lamp base assembly × 2 Lamp shade × 2 Harp&Finial × 2 E26 Bulb × 2 Manual × 1


Safefy Warning:

BULB TYPE:

Use only the bulb type and wattage indicated on Wattage Label placed on or near socket. WARNIN G: NEVER EXCEED MAXIMUM WATTAGE Indicated as bulb may cause fire.

CAUTION:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT ALTER THE PLUG!



PROPER LAMP CARE:

Use a soft cloth to dust your lamp on a regular basis. Never use chemicals or an abrasive cleaner, to do so may damage the finish on your lamp.

TROUBLESHOOTING:

If fixture does not work:

- 1. Turn off electrical power and check all wire connections.
- 2. Check fuse or circuit breaker and replace if necessary.
- 3. Check to make sure light bulb is in working order.