


INSTRUCTION MANUAL



Model:BCG-08A
Cigar CoolerHumidor
220 Vac,65 W,50Hz

NEED HELP? CONTACT US!



Have product questions? Need Technical Support?
Please feel free to contact us.

✉ After-sales e-mail: service@callsupports.com

🌐 After-sales website : Callsupports.com

☎ +1 888-968-7197 (US) 9AM - 6PM EST

For your safety

Read this guide carefully before use to know important safety instructions and use of this appliance.

Failure to follow the instructions for proper use of the appliance excludes any liability of the manufacturer for damage resulting from the product.

This appliance is intended for the production of usual amounts for the family or for non-professional uses, similar to domestic ones.

Domestic uses include, for example, The use of kitchens for staff in shops, offices, farms and other production companies, as well as the use by guest of pensions, small hotels and similar accommodation. Use the appliance only for normal quantities and working time in your household.

Please keep the operating instructions. If the equipment is sold to a third party, deliver this instruction manual together.

General safety instructions

Danger of electric shock.

Use of this appliance is forbidden to children.

Keep the appliance and its connecting cable out of reach of children.

Devices may be used by people with reduced physical, sensory or mental capabilities or by people with no experience or expertise if they are supervised or instructed about the safe use of the device and understood the dangers arising from it.

Children are forbidden to play with the appliance!

Connect and use the appliance only in accordance with the nameplate data.

Make sure that the electrical voltage of the appliance corresponds to that of your electric power supply.

When the appliance is plugged in, it must be used in closed environments only. Use only if the power cord and the appliance are free of damage.

Before replacing accessories or spare parts that move during operation, the appliance must be switched off and disconnected from the mains.

Always disconnect the unit from the mains when it is unattended and before mounting, disassembling or cleaning.

Do not pull the power cord on sharp edges or contact hot surfaces.

In order to avoid dangers, if the power cord of this appliance is damaged, it must be replaced by the manufacturer, its customer service or by persons with similar qualifications.

When using electrical extensions, this is not recommended, they must be adapted to the power of the appliance, in order to avoid hazards to the operator and to the safety of the environment where it operates.

Repairs to the appliance only from our customer service department.

Cleaning And Maintenance

Before any cleaning operation, unplug the power cord from the electrical outlet and wait 5 minutes.

Technical data

Power 65W

Power supply 220VAC~50Hz

Identification Data

Item:Personal Cigar

Humidor Cooler

Model:BCG-08A

Volume:8L

Climate Class:N

Voltage: 220VAC

Frequency: 50Hz

Power: 65 Watt

Energy Consumption: 0.273 kWh / 24h

Foaming gas: cyclopentane

Product description

1- TEMPERATURE

Adjustable from 54-72 F 12-22C

2-HUMIDITY

monitor allows the user to manually maintain RH Levels as needed.

3-LOCK

Lockable with provided key(s) for added security.

4-GLASS TOUCH PANEL

For easy user control.

5-SPANISH CEDAR WOODEN SHELVES

with 1 Shelf and 1 Box

6- TEMPERED GLASS DOOR

with UV protected coating. Keep out of direct sunlight to minimize UV exposure.


7-HEATING PIPE CROSS THE FOAMING BODY

With Heating function

8-BUILT IN MOISTURE TANK

Add purifier water to provide humidity for your cigars.;Place Humidity control pack(55-70%) would be better!

This product complies with ETL regulations.



Operation of the refrigerator

Clean the interior before use.

Fix the shelves correctly in the appropriate guides.

How to use the buttons on the display panel



BUTTON FUNCTIONS:



Turn the light on or off.



Raise the desired temperatures.*



Lower the desired temperatures.*



Alter the temperature display to Fahrenheit or Celsius.*

* The interior temperature can be adjusted in increments of 1 degree between 54° and 72°F.

After turning on the device, the LED display will show the ambient temperature first, and then the internal cabinet temperature.

After you set the desired temperature, this set temperature will flash for 5 seconds on the display and then revert back to the internal cabinet temperature.

If there is humidity difference between the door display and the inner actual humidity. Please press the button "  " and "  " at the same time for 3 seconds, to adjust the consistency of humidity

Note:

When using the device for the first time or restarting after being turned off for a long time, there may be a variation of a few degrees between the operation temperature and the temperature indicated on the LCD display.

This is normal and is due to the length of the activation time.

Once the cigar cooler is running for a few hours everything will return to normal.

Special precautions

Please disconnect the device before making any movement of the device. If the move involves a long distance, please use a cart for delivery.

Please check whether all parts have no injuries or tampering before installation.

To function properly, this device must be placed flat, with spaces of 5 cm on each side and 10 cm on the back.

Keep the ventilation holes free and keep a distance of 5 cm from them.

Please keep away from heat or gas sources.

Avoid direct sun and away from heat sources that emit high temperatures.

Do not place heavy objects on top of the device.

Seasoning Your Cigar Cooler

It is best to season your wood shelves and drawers before adding your cigars so that the wood is at an ideal relative humidity (RH) and does not absorb humidity from your cigars. To season your new cigar cooler:

1. Add distilled water to the included moisture container or add a sponge that is damp with distilled water. Make sure that the water is not touching the wood directly or this may damage the wood.
2. Allow the moisture container, or other humidity-adding device, to sit in the cooler until it reaches a relative humidity of 5% higher than your preferred level. This process may take as long as 3 days but is the best way to ensure your cigars stay optimal.
3. Once the cooler reaches this mark, you can begin to add cigars. You may add a few at a time in order to monitor the RH and make sure it stays at a level you want it at. If it drops too much, you can use the same seasoning method to bring it back up.

During this entire process, it is recommended to not open the door unnecessarily, as this lets moisture escape and can delay the process.

Maintenance

Turn off the power before cleaning the device.

Remove cigars and shelves, then clean the cabinet with a slightly damp cloth soaked in clean water.

Do not use soap or detergent for washing inside or outside the device.

Clean the device regularly.

General safety precautions

After removing the device from the package, make sure it is in good condition.

If in doubt, do not use it and contact an authorized service center.

Plastic bags, polystyrene and any other packaging materials must be kept out of the reach of children.

This cooler can only be used in the use it was designed for.

The manufacturer will not be liable for any damage due to improper use or repairs by unqualified personnel.

Before cleaning the cooler, make sure it is unplugged.

Never clean the unit with an acidic, medical preparation, dilution, petrol, oil or any other type of chemical that could damage the device.

Repair must only be performed by authorized service centers.

Caution:

1. In case of breakage of the fuse, it is recommended to replace it only with the same type of fuse, to prevent any fire.
2. Do not use multi-sockets to connect the device.
3. Do not use extension cords.

Warning:

1. If the power cord is damaged, it must be replaced by the manufacturer or an authorized service center or a similarly qualified person to avoid hazards.
2. Please unscrew the door before throwing it away.
3. Please keep the appliance away from flammable substances.
4. To avoid a danger due to the instability of the appliance, it must be repaired according to the instructions.
5. Do not use electrical devices inside the appliance's storage compartments.
6. This appliance is not intended for use by persons (including children) with reduced physical condition,
7. Children should be supervised to ensure that they do not play with the appliance.
8. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have received supervision or instructions regarding the use of the appliance by a person responsible for their safety.
9. Keep indoor and outdoor ventilation openings free from obstructions and obstructions to prevent overheating of the appliance.

Warnings on scrapping and disposal



This appliance is marked in compliance with USA WEEE standard on waste electrical and electronic equipment.

At the end of its useful life the product must not be disposed of together with waste urban.

The directive prescribes the regulatory framework for the collection and recycling of discarded appliances throughout the EU.

It can be delivered to the appropriate separate collection centers set up by the municipal administrations, or to dealers who provide this service.

Disposing of an electrical appliance separately avoids possible negative consequences for the environment and health deriving from its inadequate disposal and allows the recovery of the materials it is made of in order to obtain an important saving of energy and resources.

MADE IN CHINA