


HOW TO SET TIME


VERY IMPORTANT:

The Nightingale is silent from 10PM till 5AM (22:00 till 05:00). In order to set the hourly chime correctly, please make sure you follow the steps below

1 DON'T PUT THE BATTERY IN THE CLOCK YET




2



SET TIME TO 5:45 FIRST

3

3 X AA




PUT THE BATTERY IN THE NIGHTINGALE

TIME IS NOW 5:45AM

4

It is 05:45AM now. If you need to set the time between 05:45PM (17:00) and 05:44AM (05:44), move the hands 12h forward first



SET CURRENT TIME

NOTE:

Press the SET button to test the bird singing if needed

Each time the SET button is pressed, please take out the batteries and start from picture 1