

**DINING CHAIR**


---

**USER MANUAL**

1

## ASSEMBLY INSTRUCTIONS

---




### **WARNING**

- **-Assembly:** Adult assembly required.  
CHOKING HAZARD: Small screws and parts can pose a choking risk. Keep them away from children under 3 years old.
- **-Packaging:** Keep these packaging materials out of reach of children.
- **-Inspection:** check the product for wear and tear, and any part is damaged, missing, or has loose screws. Check all fasteners regularly.
- **-Weight Limit:** 300 lbs.
- **-Safety:** Keep away from heat sources.
- **-Storage:** Do not leave outdoors or near wet surroundings.

2

## PRODUCT SPECIFICATIONS




### Product information:

Size:18\*22\*37.7nch


Net weight :12LBS

3


# PARTS LIST




(A) \*1PC




(B) \*1PC




(C) \*1PC



(D) \*1PC




(E) \*1PC




6\*16mm

(F) \*4PCS




6\*35mm

(G) \*1PC




6\*45mm


(H) \*4PCS



(I) \*11PCS



(J) \*4PCS




6\*40mm

(K) \*2PCS

4

## STEP 1


Insert A into B along the middle notch until the surface is flush.



5

## STEP 2


Align the seat cushion E with the hole on the leg AB, and lock the screw H and the washer I from below.



6

## STEP 3


Align cushion E and cushion elbow C according to the arc and hole position, then tighten screw G, screw K and gasket I from the back of C.



7

## STEP 4


Align the assembled cushion with the holes on the chair legs, and then lock the screw F and I from the back.



8

## STEP 5

After installation, adjust the foot nails J at the bottom to keep the chair balanced.




9

## STEP 6

---

Installation completed



## MAINTENANCE AND PRESERVATION

### **WARRANTY**

metal furniture are generally more durable than plastic ones, but they can sometimes break. While metal furniture can last many years with proper care, products are not guaranteed against damage due to play and use.

Products sold are guaranteed against defects in materials and workmanship for twelve (12) months from the date of original purchase. This warranty is valid only under normal use and for the intended purpose of the product.

Comfortable experience, Bringing aesthetics to life

---