

ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not Included)



(Included)

Allen Wrench



2 - People

ASSEMBLY RATING



EASY ——————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

☐ Are you missing anything?

Double-check all parts, hardware and accessories listed are all acccounted for.

☐ Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐ Check out our Quick Tips!


We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐ Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.




Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE


FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

COFFEE TABLE





PARTS

#1






Table Top
1 pc

#2



Leg
2 pcs

#3



Chassis
2 pcs

#4



Fastenings
1 pc

HARDWARE

#A



Allen Wrench
1 pc

#B



Bolt 5/16" x 3-2/16"
2 pcs

#C



Bolt 5/16" x 1-3/8"
8 pcs

#D



Bolt 5/16" x 13/16"
8 pcs

#E






Flat Washer
18 pcs

#F




Adjustable Feet
8pcs

Carton	Designation	Part		Hardware
	Table Top 1pc	#1		#A 1pc 
	Leg 2pcs	#2		#B 2pc  #C 8pcs  #D 8pcs  #E 18pcs  #F 8pcs 
	Chassis 2pcs	#3		
	Fastenings 1pc	#4		

ASSEMBLY INSTRUCTIONS


1

Part #1 x1pc
Part #2 x2pc
Hardware #A x1pc
Hardware #D x8pcs
Hardware # E x8pcs



2


Part #3 x2pcs
Hardware #A x1pc
Hardware #C x8pcs
Hardware #E x8pcs



ASSEMBLY INSTRUCTIONS

3


Part #4 x1pc
Hardware #A x1pc
Hardware #B x2pcs
Hardware # E x3pcs



ASSEMBLY INSTRUCTIONS

4

Hardware (#F) x8pc



ASSEMBLY COMOLETED

Please ensure the furniture rests on an even and flat surface.If the product wobbles or feels loose,double-check all bolts and/or screws are properly tightened and secured

Keep this handy!

Please relain this instruction manual and any order-related information for future reference.

Lift,don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intented for RESIDENTIAL USE ONLY and not for commercial use.