




TV Stand Assembly Instructions




PACKAGE CONTENT




PACKAGE CONTENT




34x




34x




37x




6x




M3x12mm
8x




8x




2x




4x




8x




4x




4x




2x



1x




1x




M4x30mm
4x


1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16



17



18



19

