

User Manual for the Record Player




The pure copper horn



The pure copper horn can be directly inserted into the speaker base gently and it can be freely rotated, simplifying the installation steps and making the operation more convenient and simple for users

Newly upgraded 360° free-spin design lets the horn connect at any angle—just plug it in and play. No tools, no tweaks, zero hassle.



USB driver music mode

USB playback supports U disk within 32GB of memory, and when it insert into the USB port, This speaker can automatically play songs from the root directory of the U disk USB driver supports MP3, WAV, FLAC formats.

The USB port can also charge devices such as mobile phones, desk lamps, etc.

Play vinyl record


Supports 7", 10", and 12" vinyl at both 33 and 45 RPM.

This turntable has an adjustable spindle, so it easily takes 12-inch records.

Attention: This part should not touch the vinyl record



Extend extension lever to maximum by hand



33/45 RPM speed selector

Pay attention to whether the stylus needle is in the center and how to replace a new one



The ruby stylus is theoretically permanent, but we recommend replacing it after using it for over 400 hours to better protect vinyl records. Be careful not to damage the stylus when using the protective cover for the stylus



The 45 RPM vinyl record with a large hole in the middle needs to be fixed with this black buckle, while other vinyl records do not require it.

BLUETOOTH MODE

Long press the first button about 3 second to turn on the device,

Short press the first button can switch to Bluetooth Mode:


Simultaneously turn on Bluetooth on the phone, search for the Bluetooth name: MJ-109LP, and once connected, you can play the music from your phone list.

Please pay attention to adjust the volume of your phone, computer, and player

Bluetooth connection is one-to-one


In Bluetooth mode, long pressing the second button 【Play / Pause】 can forcefully disconnect Bluetooth.

Please pay attention to adjust the volume of your phone, computer, and player.



When streaming over Bluetooth, loudness is set by three knobs you can't see:

1. The volume inside the app or player you're using;
2. The phone's master audio slider (open the sound menu and slide music, video, game levels);
3. The subwoofer knob on the record-player itself.



FM radio function


Firstly, press the first button briefly, switch to FM radio mode,
Then, long press the second button to enter automatic channel search
Remember to release the soft antenna behind the machine.

Audio cable mode

You can use an audio cable to connect your phone, computer, TV, etc. as an external speaker



Long press the first button about 3 second to turn on the device. Short press the first button can switch mode



- | | |
|-----------------------|-----------------|
| ① USB port | ⑥ Volume + |
| ② Power / mode switch | ⑦ Volume - |
| ③ Play / pause | ⑧ Bluetooth LED |
| ④ Previous track | ⑨ AUX in |
| ⑤ Next track | |