
# 6 DRAWER CHEST ASSEMBLY INSTRUCTIONS

**Distressed Waxed Pine** 



# IMPORTANT PLEASE READ BEFORE YOU CONTINUE FURTHER FOR DOMESTIC USE ONLY CARE AND MAITENANCE

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not drag or push items across your furniture as this may cause the surface to scratch.
- Do not place this product next to radiator or in direct sunlight.
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is Wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use soft cotton or micro fibre cloth and do not use detergents of any kind.
- Do not place on a wet or damp floor as staining may occur to your floor.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.



#### Please Note:

The parts below have been stamped with the part number/color to help identify them during assembly

#### **PARTS LIST**

| TARTS LIST  |                                |          |        |  |  |
|-------------|--------------------------------|----------|--------|--|--|
| Part Number | Part Description               | Quantity | Carton |  |  |
| 01          | Top Panel                      | 1        | 1/1    |  |  |
| 02          | Right Side Panel               | 1        | 1/1    |  |  |
| 03          | Right Front Upright            | 1        | 1/1    |  |  |
| 04          | Left Side Panel                | 1        | 1/1    |  |  |
| 05          | Left Front Upright             | 1        | 1/1    |  |  |
| 06          | Front Crossbeam Short          | 6        | 1/1    |  |  |
| 07          | Back Crossbeam                 | 1        | 1/1    |  |  |
| 08          | Back Panel                     | 2        | 1/1    |  |  |
| 09          | Drawer Runner                  | 6        | 1/1    |  |  |
| 10          | Side Foot                      | 2        | 1/1    |  |  |
| 11          | Front Foot                     | 1        | 1/1    |  |  |
| 12          | Narrow Drawer Front            | 4        | 1/1    |  |  |
| 13          | Narrow Drawer Side             | 8        | 1/1    |  |  |
| 14          | Drawer Bottom                  | 6        | 1/1    |  |  |
| 15          | Narrow Drawer Back             | 4        | 1/1    |  |  |
| 16          | Vertical Front Crossbeam Lower | 1        | 1/1    |  |  |
| 18          | Front Vertical Crossbeam       | 1        | 1/1    |  |  |
| 19          | Central Drawer Runner          | 3        | 1/1    |  |  |
| 20          | Back Vertical Crossbeam        | 1        | 1/1    |  |  |
| 24          | Wide drawer front              | 2        | 1/1    |  |  |
| 25          | Wide Drawer Side               | 4        | 1/1    |  |  |
| 26          | Wide Drawer Back               | 2        | 1/1    |  |  |






- \* Please check contents and read the instructions before commencing assembly.
- \* Assemble this product following the enclosed instructions carefully.
- \* Please take care to avoid damaging panels during assembly.


<sup>\*</sup> Use of power tools to assemble this product will invalidate any claim and damage this product making it unsafe !!!

<sup>\*</sup> Please assemble on a clean soft surface to avoid damage.


## **FITTINGS**

| Α | Ø8 x 30mm   | 88 |
|---|-------------|----|
| В | Ø3,5 x 30mm | 47 |
| С | Ø3,0 x 30mm | 56 |
| D | Ø4,0 × 40mm | 20 |
| Е | 8 x 8mm     | 30 |
| F | 3/16 x 5/8  | 06 |
| G |             | 06 |
| Н |             | 06 |
| I | 1032mm      | 01 |
| K | Strap       | 01 |
|   | Washer      | 02 |








#### **TOOLS REQUIRED**







































































### **WARNING**

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

