# **Assembly-Free Dog Crate**



**PS-DC108-31/41** 



#### How to use the tag:

- 1. Write your dog's name or Christmas blessings with chalk. (Chalks Included)
- 2. Customize a dog name sticker or Christmas blessings. (Sticker Not Included)
- 3. Attach the photo of you and your dogs with the magnetic kit. (Magnetic Paws Included)

Step 1 Take the foldable dog crate out of the box and unfold it as illustrated below.



 Firstly, cut the yellow fixing cable ties with scissors(scissors not included). During this process, please hold the wooden panels firmly to prevent them from suddenly falling and getting damaged.
Then, put your fingers through the small hole on the buttom plate and let the bottom plate down slowly.





**NOTE:** Press here to unlock

**NOTE:** Press here to lock

Turn over the bowl holders, and place the two dog bowls.



And extra force is needed to lock the latch. Don't worry, we've designed it this way intentionally to avoid the doorlock noise while the dog is eating.



The bowl holders have two different heights. The lower height for small breeds can only be used outside of the door

> **NOTE:**Press two ends to attach or remove the holders. Based on your needs, you can adjust it to the proper height.

PRESS

PRESS

The dog bowls can be placed outside or inside the cage. Just pull the latch shown in the picture, rotate the bowl-door inward and put down the latch.

