

























PARTS					
A 1pc					
B 1pc					
C 2pcs					
D 4pcs					
E 2pcs					
F 2pcs					
G 2pcs					
H 2pcs					
J 1pc		K 1pc			
L 4pcs		M 4pcs			
N 4pcs		P 4pcs			
Q 8pcs		R 1pc			
S 1pc		T 2pcs			
①	 M6x16 mm	35pcs+1pc	②	 M6x20 mm	8pcs+1pc
③	 M6x28 mm	4pcs+1pc	④	 M6	4pcs+1pc




Step1:Put one Part C and one Part B on two sides of Part E. Use Screw① to tighten Part C and E,Part B and E.Put Part G vertically on Part C and tighten them with Screw①. Put Part H vertically on part B and tighten them with Screw①.

①




Step2:Use Part N and Screw① to tighten Part G and H.

②




Step3:Put Part J on Part F,and tighten them with Screw①. Then use Screw① to tighten Part F and Part A or B or C.

③



Step4:Insert Part D to Part K,make them tight enough.


④



Step5:Put the end of Part D on the top of four standing legs, use Screw③ and Nut④ to tighten them.


⑤

Press the button and push the extension tube (M) up to the end




Step6:Press the button of Part M and push the Part M up to the end. ⑥

Pull out the extension tube (M) outwards to adjust the ceiling (R)




Step7:Press the button and Pull out the extension tube(Part M) outwards to adjust the ceiling(Part R).Part S should be done as Part R.

⑦



Step8:Put Part P on Part L,then insert Part A or B or C to the Part L, align the holes of them,then use Screw② to tighten them.

⑧



Step9: Fix the foot pad to the ground with Part Q, then you can use the grill gazebo.

⑨