



Product Manual: 12-in-1 Vegetable Chopper & Slicer

Brand: LJGDeals

Model: HG_MultiKitchenTool_GPCT2055

1. Overview

Thank you for choosing the LJGDeals 12-in-1 Vegetable Chopper. This kitchen tool is designed to cut prep time in half, offering a safe and efficient way to dice, slice, and grate vegetables and fruits.

2. Package Contents

- 1 x Main Catch Tray (with non-skid base)
- 1 x Slicer Lid with integrated cleaning fork
- 3 x Interchangeable Dicer Blades (Small 11mm, Medium 12mm, Large 17mm)
- 1 x Hand Protector (Safety Guard)
- 1 x Cleaning Fork

3. Safety Instructions

 **WARNING:** The stainless steel blades are extremely sharp. Handle with care during assembly, use, and cleaning.

- **Always** use the provided hand protector when slicing smaller pieces of food.
- Keep out of reach of children.
- This product contains materials known to the State of California to cause cancer (Prop 65). For more info, visit [P65Warnings.ca.gov](https://www.p65warnings.ca.gov).

4. How to Use

1. **Setup:** Place the catch tray on a flat, dry surface.
2. **Insert Blade:** Select your desired blade and snap it into the square slot on the lid.
3. **Prep Food:** Cut vegetables (like onions or potatoes) into smaller chunks that fit within the blade area.
4. **Chop:** Place the food on the blade and press the lid down firmly in one swift motion.
5. **Empty:** Remove the lid to access your diced food in the tray.

5. Cleaning & Maintenance

- **Disassemble:** All parts are detachable for easy cleaning.

- **Cleaning Fork:** Use the small fork stored inside the lid to remove food debris stuck in the teeth of the pusher.
 - **Wash:** Hand washing is recommended with mild soap and warm water to maintain blade sharpness.
 - **Storage:** Store blades inside the catch tray when not in use to save space and prevent injury.
-