

If there are any missing parts, damaged packaging or broken panels,
please contact our service email for assistance:

furni-service@outlook.com

CONTACT US!

Do Not return this product

If you encounter any missing parts, damaged packaging, or broken panels, please contact our customer service team for assistance:

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④





WhatsApp


For faster resolution:

① Include your **order number** ② Attach **clear photos** of the issue














We appreciate your patience and cooperation, and we'll do our best to resolve your concern promptly. Thank you!




x 3







x 3



A  40+2PCS	B  40+2PCS	C  $\text{Ø}6*30\text{MM}$ 34+2PCS	D  M4*10MM 3PCS
E  3PCS	F  M4*30MM 28+2PCS	G  32+2PCS	H  M3*16MM 32+2PCS
I  2PCS	J  $\text{Ø}4*35\text{MM}$ 2PCS	K  2PCS	L  $\text{Ø}4*12\text{MM}$ 2PCS
M  40+2PCS	N		

STEP 1






	A*40PCS		C*34PCS		L*2PCS		I*2PCS
---	---------	---	---------	---	--------	--	--------



STEP 2






STEP 3




STEP 4




STEP 5






STEP 6




	F*6PCS
---	--------



STEP 7




	B*6PCS		M*6PCS
---	--------	---	--------


STEP 8





	B*6PCS		M*6PCS
---	--------	---	--------





STEP 9




STEP 10





	B*6PCS		M*6PCS
---	--------	---	--------


STEP 11





STEP 12





STEP 13







STEP 14





	B*10PCS		M*10PCS
---	---------	---	---------



STEP 15




	G*32PCS		H*32PCS
---	---------	---	---------

STEP 16






	J*2PCS		K*2PCS
---	--------	---	--------

STEP 17



x3



	D*3PCS		E*3PCS
---	--------	---	--------

THANK YOU!

Contact our friendly
customer service team first for help

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④



WhatsApp

If you have any questions, please leave the **order No.**
and **related picture** information, we will reply you
within 24 hours, and solve the problem as soon as possible.