

Congratulations on your latest our purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time. Good luck --though we're confident you won't need it.

before you begin

- 1. Check for damaged or missing parts. Customers can email or call to order missing supplies.
- 2. Use the carton as a working surface to prevent product damage during assembly.
- 3. Gather all tools prior to assembly.

tools needed




table of contents

••••••

introduction 2
hardware 4
parts list 5
assembly 6-9

hardware

(A) x 4

5/16" x 3-1/4" round hex screw



(B) x 2


5/16" x 2-1/4" round hex screw




(C) x 4

5/16" x 2" round hex screw









(D) x 10

5/16" lock washer




(E) x 10

7/8" flat washer



(F) x 1

5mm Ball end Hex wrench




ITEM DESCRIPTION QUANTITY

••••••••••••


1 chair back 1

(2) seat cushion 1

3 front leg
2




step 1.




Please do not assemble with power tools

step 2.



Please do not assemble with power tools

step 3.



(A) x 4

5/16" x 3-1/4" round hex screw






(D) x 4

5/16" lock washer




(E) x 4

7/8" flat washer



(F) x 1

5mm Ball end Hex wrench



Please do not assemble with power tools


step 4.

A friendly reminder from us:

Please keep the Allen wrench.



After a period of time, there may be a chance the KD furniture may become loose, please use an Allen wrench to tighten the loose bolts.



(This part is already attached on the end cap of 4 legs.)

Level the furniture, use leveling feet if needed.