BOOKCASE



ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!


1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2.This product is for home use only and not intended for commercial establishment.





ASSEMBLY TIME PER UNIT: 40 MINUTES

PARTS IDENTIFICATION:



Z	HARDWARE PACKAGE										
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY				
1	GLUE 40g		1PC	5	BOLT § 9.5x55mm FOR BOTTOM PANEL		24PCS				
2	WOODEN DOWEL § 8x30mm		48PCS	6	FOOT 50x50x18mm		5PCS				
3	CAM BOLT § 7x35.5mm		24PCS	7	SCREW § 5x22.5mm FOR FOOT		10PCS				
4	CAM LOCK § 15x12mm		24PCS	8	STICKER § 20mm		4PCS				

Z	HARDWARE PACKAGE									
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY			
9	ANTI-TIP STRAP 170x15mm		2PCS	11	LONG SCREW	AUTUUTUU A	2PCS			
10	WALL PLUG 6x30mm	and the second	2PCS	12	SCREW Ø4x16mm	WILLIAM ST	2PCS			

