






Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.


HARDWARE LIST DESCRIPTION		U915-30 Bolero Sofa	U915-20 Bolero Loveseat	U915-10 Bolero Chair
A	 WOODEN LEG	4 PCS	4 PCS	4 PCS
B	 M8 x 60 JCBB BOLT	4 PCS	4 PCS	4 PCS
C	 M5 ALLEN KEY	1 PC	1 PC	1 PC



U915-20 Bolero Loveseat



U915-30 Bolero Sofa



U915-10 Bolero Chair

Step 1:

There is a zipper at the bottom of each sofa, loveseat and chair with a sign "LEGS INSIDE". Open the zipper and take out the legs and hardware package.

Step 2:

Place a wooden leg (A) on to the bottom of the upholstery that you are building. Make sure the hole on the wooden leg (A) aligns with the hole on the bottom of the upholstery. Tighten the wooden leg (A) with the bolt (B) by using the allen key (C). Repeat the same method until all the legs been assembled.

