

WARNING!!

Children have died from furniture tipover. Tip restraints have been included with this product; you must install the tip restraints according to these instructions in order to minimize the risk of furniture tipping.

NEVER allow children to climb or hang on furniture, including drawers or cabinet doors.

In addition to installing the restrains, to help prevent tip-over

1. NEVER put a TV or other heavy objects on top of this product".
2. Do not stand on the product

⚠ WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: -ALWAYS install anti-tip device provided. -NEVER put a TV on this product. -NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves. -NEVER open more than one drawer at a time. -Place heaviest items in the lowest drawers.
	<i>This is a permanent label. Do not remove!</i>

⚠ WARNING	
	This product is NOT a Clothing Storage Unit (CSU). DO NOT use it for clothing storage. Improper use may cause furniture tipover.

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance


-  ● Not for commercial use. For residential use only.
-  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
-  ● Do not put hot items directly on furniture surface.
-  ● Do not clean furniture with harsh cleansers or polish.
-  ● Do not place furniture under direct sunlight.
-  ● Do not place furniture near heating or cooling vents.
-  ● Do not write on furniture without a padded barrier to protect the surface.
-  ● Do not place furniture outside . For indoor use only.
-  ● Stains may be removed with mild soap solution and damp cloth.
-  ● Children should not climb or jump on the furniture.
-  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.


Sideboard Cabinet





N780P455270

N780P455271






N780P455271 Parts List

Label	Picture	Description	QTY
Ⓐ		Top Panel	1

Ⓑ		Bottom Panel	1
Ⓒ		Back Panel	1
Ⓓ		Back Panel	1
Ⓔ		Back Panel	1
Ⓕ		Left Door Panel	1
Ⓖ		Right Door Panel	2
Ⓕ		Table Base	2
Ⓖ		Table Base	1
Ⓙ		Adjustable Panel	3
Ⓚ		Drawer Bottom Panel	3

N780P455270 Parts List

Label	Picture	Description	QTY
(L)		Left Side Panel	1
(M)		Right Side Panel	1
(N)		Middle Left Side Panel	1
(O)		Middle Right Side Panel	1
(P)		Drawer Panel	3
(Q)		Drawer Left Side Panel	3
(R)		Drawer Right Side Panel	3
(S)		Drawer Back Panel	3
(T)		Leg	4
(U)		Leg	1

N780P455270 Hardware






Label	Picture	Description	QTY
①		Bolt (Ø6*35mm)	12+1
②		Bolt (Ø6*40mm)	4+1
③		Bolt (Ø6*55mm)	4+1
④		Flat Washer	20+2
⑤		Hinge	6
⑥		Two-Section Slide Rail(11")	6
⑦		Cam Bolt (Ø6*35mm)	16+2
⑧		Cam Nut (Ø15*9mm)	16+2
⑨		Handle	6
⑩		Bolt (Ø4*22mm)	3+1
⑪		Bolt (Ø4*25mm)	3+1
⑫		Dowel (Ø8*20mm)	12+2
⑬		Dowel (Ø8*30mm)	4+1
⑭		Screw (Ø3.5*12mm)	18+2
⑮		Screw (Ø3.5*14mm)	42+4
⑯		Screw (Ø3.5*25mm)	12+1
⑰		L-type Hexagon Wrench	1
⑱		Plastic Button	12+1
⑲		Screw (Ø3*16mm)	12+1
⑳		Shelf Pin	12

Restraint Device Hardware

21		Anti-Tipping Iron Sheet	2
22		Nut	2
23		Screw (Ø4*14mm)	2
24		Screw (Ø4*35mm)	2

Assembly Preparation

Before
Beginning
Assembly:





- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Cabinet has multiple parts and may require up to 60 minutes to assemble, have 2 adults on hand for assembly. To give you an overview of the Cabinet parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Open the Two-section Slide Rail (6) and divide it into (6-1) and (6-2).

Step 2




Attach the Two-section Slide Rail ((6-1)) to the Left Side Panel(L) and the Right Side Panel(M) with Screw((15)) using L-type Hexagon Wrench((17)).

Step 3



Attach the Two-section Slide Rail (6-1) to the Middle Left Side Panel(N) with Screw(15) using L-type Hexagon Wrench(17).


Step 4



Attach the Two-section Slide Rail (6-1) to the Middle Right Side Panel(O) with Screw(15) using L-type Hexagon Wrench(17).

Step 5


Cam Bolt (7) x4
L-type Hexagon Wrench (17) x1



Attach Cam Bolt((7)) to the Bottom Panel(B) using L-type Hexagon Wrench((17)).

Step 6


Bolt (2) x2
Flat Washer (4) x2
Dowel (12) x2
L-type Hexagon Wrench (17) x1



Fix the Dowel((12)) to the Bottom Panel(B).


Attach the Left Side Panel(L) to the Bottom Panel(B) with Bolt((2)) and Flat Washer((4)) using L-type Hexagon Wrench((17)).

Step 7




Fix the Dowel(⑫) to the Left Side Panel(L).
Attach the Left Side Panel(L) to the Table Base(H) with Bolt(①) and Flat Washer(④) using L-type Hexagon Wrench(⑰).

Step 8




Fix the Dowel(⑫) to the Middle Left Side Panel(N).
Attach the Middle Left Side Panel(N) to the Bottom Panel(B) with Cam Nut(⑧) using L-type Hexagon Wrench(⑰).

Step 9




Fix the Dowel(13) to the Middle Left Side Panel(N).
Attach the Middle Left Side Panel(N) to the Table Base(H,I) with Bolt(3) and Flat Washer(4) using L-type Hexagon Wrench(17).

Step 10




Fix the Dowel(12) to the Middle Right Side Panel(O).
Attach the Middle Right Side Panel(O) to the Bottom Panel(B) with Cam Nut(8) using L-type Hexagon Wrench(17).

Step 11




Fix the Dowel(13) to the Middle Right Side Panel(O).
Attach the Middle Right Side Panel(O) to the Table Base(H,I) with Bolt(3) and Flat Washer(4) using L-type Hexagon Wrench(17).

Step 12




Fix the Dowel(12) to the Right Side Panel(M).
Attach the Right Side Panel(M) to the Bottom Panel(B) with Bolt(2) and Flat Washer(4) using L-type Hexagon Wrench(17).
Attach the Right Side Panel(M) to the Table Base(H) with Bolt(1) and Flat Washer(4) using L-type Hexagon Wrench(17).

Step 13




Please install the Leg (T,U) to the Bottom Panel(B).

Step 14




Insert the Back Panel(C) into the groove of the Left Side Panel(L) and the Middle Left Side Panel(N).
Insert the Back Panel(D) into the groove of the Middle Left Side Panel(N) and the Middle Right Side Panel(O).
Insert the Back Panel(E) into the groove of the Right Side Panel(M) and the Middle Right Side Panel(O).

Step 15




Attach the long side of Anti-tipping Iron Sheet (21) into the Left Side Panel(L) and the Right Side Panel(M) with Screw(23) using L-type Hexagon Wrench(17).

Step 16




Attach the Top Panel(A) to the Left Side Panel(L), the Middle Left Side Panel(N), the Middle Right Side Panel(O) and the Right Side Panel(M) with Bolt(1) and Flat Washer(4) using L-type Hexagon Wrench(17).

Step 17




Attach the Two-section Slide Rail (6-2) to the Drawer Left Side Panel(Q) and the Drawer Right Side Panel(R) with Screw(14) using L-type Hexagon Wrench(17).

Step 18



Attach the Drawer Back Panel (S) to the Drawer Left Side Panel(Q) and the Drawer Right Side Panel(R) with Screw (16) using L-type Hexagon Wrench(17).
Insert the Drawe Bottom Panel(K) into the groove of the Drawer Left Side Panel(Q),the Drawer Right Side Panel(R) and the Drawer Back Panel(S).

Step 19




- ⑦ x8
- ⑨ x3
- ⑩ x3
- ⑰ x1

x3

Attach Cam Bolt(⑦) to the Drawer Panel(P) using L-type Hexagon Wrench(⑰).
Attach Handle(⑨) to the Drawer Panel(P) with Bolt(⑩) using L-type Hexagon Wrench(⑰).

Step 20




- ⑧ x8
- ⑰ x1

x3

Attach the Drawer Panel(P) to the Drawer Left Side Panel(Q) and the Drawer Right Side Panel(R) with Cam Nut(⑧) using L-type Hexagon Wrench(⑰).


Step 21



Please put the drawer in the table.


Step 22

🔧 20x12



Inset Shelf Pin(20) into the Left Side Panel(L),the Middle Left Side Panel(N),the Middle Right Side Panel(O) and the Right Side Panel(M).
Put Adjustable Panel(J) on Shelf Pin(20).


Step 23



Attach Handle(9) to the Left Door Panel(F) and the Right Door Panel(G) with Bolt(11) using L-type Hexagon Wrench(17).

Attach Hinge(5) to the Left Door Panel(F) and the Right Door Panel(G) with Screw(15) using L-type Hexagon Wrench(17).


Step 24



Attach the Left Door Panel(F) to the Left Side Panel(L) with Screw(15) using L-type Hexagon Wrench(17).

Attach the Right Door Panel(G) to the Middle Right Side Panel(O) and the Right Side Panel(M) with Screw(15) using L-type Hexagon Wrench(17).


Step 25




- 18x12
- 19x12
- 17x1

Attach Plastic Button(18) into the Back Panel(C,D,E) with Screw(19) using L-type Hexagon Wrench(17).

Step 26





- 21x2
- 22x2
- 24x2
- 17x1



Screw the Nut (22) into the wall.
Install the short side of Anti-tipping Iron Sheet(21) on the wall with Screw(24) using L-type Hexagon Wrench(17).

Step 27



Adjust Pre-installed Levelers
height to achieve balance.

Your cabinet is ready for use.

Questions & Answers about Proposition 65

• What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm.

These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals. Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water. Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

• What types of chemicals are on the Proposition 65 list?

The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust.

• What does a warning mean?

If a warning is placed on a product label or posted or distributed at a workplace, a business, or in rental housing, the business issuing the warning is aware or believes that it is exposing individuals to one or more listed chemicals. By law, a warning must be given for listed chemicals unless the exposure is low enough to pose no significant risk of cancer or is significantly below levels observed to cause birth defects or other reproductive harm.

• Where can I get more information on Proposition 65?

If you have specific questions on the administration or implementation of Proposition 65, you can contact OEHHA's Proposition 65 program at P65.Questions@oehha.ca.gov, or by phone at (916) 445-6900.