
6 DRAWER CABINET

Assembly Instructions – Please keep for future reference



Dimensions	No. people	Assembly Time	OW #
Width :120 cm Depth: 39 cm Height: 77 cm		90 mins (approx)	CHTARD6WT

Important

- PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY
- PLEASE DO NOT THROW THE PACKAGING AWAY UNTIL YOU ARE SATISFIED WITH PURCHASE, GOODS NEED TO BE RETURNED IN ORIGINAL PACKAGING.

⚠ Safety and Care Advice

Important

- PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY
- PLEASE DO NOT THROW THE PACKAGING AWAY UNTIL YOU ARE SATISFIED WITH PURCHASE, GOODS NEED TO BE RETURNED IN ORIGINAL PACKAGING.

- Check you have all the components and tools listed on pages 4 and 5.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.




- Dispose of all packaging carefully and responsibly.

Warnings

CHILD SAFETY

ANCHOR AND PROTECT A CHILD
Use of anti-tip kit is required



·Place heaviest items in the lowest drawers.
·Useless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
·Never allow children to climb or hang on drawers, doors or shelves.
·Never open more than one drawer at a time.
·Do not defeat or remove the drawer interlock system.
·Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.

CLIMBING MAY RESULT IN SERIOUS INJURY

Care and Maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

If kept outside please ensure in the winter months that the product is correctly covered or put away into a dry environment to prevent corrosion, weathering or damage.

If your product is not designed to be outside, we recommend that it is always kept indoors in a dry environment.

If you are unhappy with the product and wish to return it, please follow the retailer's returns procedure.

Exploded View



Components - Panels

Please check that you have all the components listed below before constructing your item.

Part No	Description	Qty	Size (mm)	Thickness (mm)
1	Top Panel	1	1200x390 mm	15 mm
2	Left Side Panel	1	750x337 mm	15 mm
3	Left Front Strip	1	750x50 mm	25 mm
4	Middle Board	1	750x351 mm	15 mm
5	Right Side Panel	1	750x337 mm	15 mm
6	Right Front Strip	1	750x50 mm	25 mm
7	Rail Block	6	290x40 mm	9 mm
8	Front Decoration Strip	6	567x45 mm	15 mm
9	Front Bottom Support Strip	2	576x80 mm	15 mm
10	Upper Back Panel	1	1175x297 mm	2.5 mm
11	Lower Back Panel	1	1175x297 mm	2.5 mm
12	Upper Back Support Strip	1	1168x85 mm	15 mm
13	Lower Back Support Strip	1	1168x85 mm	15 mm
14	Drawer Left Side Panel	6	299x130 mm	12 mm
15	Drawer Right Side Panel	6	299x130 mm	12 mm
16	Drawer Back Side Panel	6	518x130 mm	12 mm
17	Drawer Bottom Support Strip	6	286x50 mm	12 mm
18	Drawer Bottom Panel	6	525x294 mm	2.5 mm
19	Left Drawer Front Panel	3	569x198 mm	15 mm
20	Right Drawer Front Panel	3	569x198 mm	15 mm







Important – Please read these instructions fully before starting assembly

Components - Fixings




Please check that you have componts listed below constructing your item.

Note: The quantities below are the correct amount to complete the assembly. Insome cases more fittings may be supplied than are required.


HARDWARE

(A)  Cam Bolt M15x10mm X 72+7	(B)  Cam Lock M15x10mm X 72+7	(C)  Dowel M6x30mm X 16+1	(D)  M4x40mm X 36+3	(E)  M3.5x12mm X 48+4
(F)  M4x20mm X 12+1	(G)  Back panel clip X12+1	(H)  M3x16mm X 12+1	(I)  Leg Pin X 6	(M)  Dowel M6x50mm X4
(N)  Dowel M6x15mm X12+1	(CL)  Drawer Slide X 6	(CR)  Drawer Slide X 6	(DL)  Drawer Slide X 6	(DR)  Drawer Slide X 6


ANTI-TIPPING KITS

(J)  L-shaped anti-tip metal plate X2	(K)  Wall Plug X 2	(L)  M4x12mm X 2

Tools Required (Not Provided)



Ruler - Use this to measure your screws (mm)





Important-Please read these instructions fully before starting assembly


If you need help or have damaged or missing parts, please email

Assembly Instructions


Step 1










Step 2












Step 3



④
②
⑤
Ⓘ



Ⓘ x6
Leg Pin

Step 4



M6X30mm
M6X50mm
M6X15mm
Ⓒ
Ⓜ
Ⓝ


Ⓕ
7
Ⓝ
2
5



Ⓕ x12
M4x20mm



Ⓝ x12
Dowel M6x15mm


Step 5





A
E
CL
2



E
CL



A
x9
Cam Bolt M15x10mm



E
x6
M3.5x12mm



CL
x3
Drawer Slide


Step 6





A
E
CR
5



E
CR



A
x9
Cam Bolt M15x10mm



E
x6
M3.5x12mm



CR
x3
Drawer Slide


Step 7






90°
A
E
CR
4
CL


E
CL
CR



A
x10
Cam Bolt M15x10mm



E
x12
M3.5x12mm



CL
x3
Drawer Slide


CR
x3
Drawer Slide


Step 8


M6X30mm
M6X50mm
M6X15mm
C
M
N






B
8
4
M
9

B
x10
Cam Lock M15x10mm



M
x3
Dowel M6x50mm


Step 9








Step 10














Step 11




Step 12





Step 13




Step 14










Step 15













Step 16










Step 17







Step 18










x6




Step 19







x6



Step 20

