













ASSEMBLY INSTRUCTION OW-MY7090BY


	X1		X1		X2		X2
A BACK		B SEAT		C FRONT LEGS		D SIDE SUPPORT	
	X1	 M6X60	X5	 M6X65	X4		X6
E FRONT SUPPORT		F SCREWS		G SCREWS		H SCREWS	
	X9		X9		X1		
I SPRING WASHER		J WASHER		K HEX KEY			

1




Attach part B seat to part A back with five part J washers, five part I spring washers, and five part F screws.

2




Attach part C front legs to the seat with two part J washers, two part I spring washers, and two part G screws per leg.

3




Attach part E front support to the front legs with two part H screws.

4



Attach part D side supports to front legs and back legs with two part H screws per side.

5



Close the undercarriage.

