

Brightech[®] MAXWELL FLOOR LAMP

(2)




Place frame (I) on a flat surface. Insert four (B) screws into the frame and into the short poles (H) and screw until tight. Then slide the shades (K) into the short poles.




Pull the socket and cord through socket board G's hole and turn to tighten. Then, insert the stud bolts **(E)** into the board and into the short poles **(H)** and screw tight.


Note: The direction of the socket opening must be downward when you screw the socket board and short poles together.




Screw four long (D) poles and (F) shelves together with the (E) screws until tight. Repeat this step to build another level.



Screw four long (D) poles and (F) shelves together with the (E) screws until tight. Repeat this step to build another level.





Extend Your Warranty From 3 Years To 5 Years

To extend your warranty by an extra 2 years for a total of 5 years' warranty, register your purchase by filling in the brief form at brightechshop.com/pages/extended-warranty/.

Thank you for your purchase of your Brightech lamp. Please contact us via our website or email if you have any issues. www.brightechshop.com wecare@brightechshop.com