

Hardware:



(8) Hex Screws



(1) Wrench



(1) Allen Wrench



(4) Hollow Rods
(Adj. Legs Only)




(8) Washer and Nut Sets

Step 1: Slide hex screw through leg and corner bracket holes.


Step 2: Slide a washer and nut onto the hex screw and begin tightening them with the included wrenches

Wooden Legs



Adjustable Legs

**Only top hole of the leg uses hollow rod.*



Please check the contents to make sure nothing is missing or damaged.

For assistance please contact Customer Service at 1-800-247-8465

Caution

Do not over-tighten the fasteners.


This product is not intended for, nor is it suitable for standing or being climbed on.

Caring for your Wood Designs Table:

To clean the wooden top, use a soft cloth moistened in warm soapy water. After cleaning, buff with a dry clean cloth. Do not leave any water on the wooden surface.

Save your wrenches:

Periodically check the stability and security of the desk. If necessary, tighten the fasteners to maintain the stability and strength of the table.



**Assembly Instructions
for Tables**



Wood Designs
EARLY LEARNING FURNITURE