


ASSEMBLY INSTRUCTIONS

Coffee Table



Guidelines

FAILURE TO FOLLOW THESE WARNINGS WHEN IN USE COULD RESULT IN INJURY

- Do not stand on the item or use as a step ladder
- Do not use this item unless all bolts and screws are firmly secured and fastened.
- Check all bolts and screws every 90 days. As necessary tighten if any are loose.
- Lift up then move. Pushing over or dragging this product can result in an injury or cause damage to the floor and piece.

Pre-Assembly Preparation:


Please read through this instruction booklet before beginning assembly of this item.

Two adults are recommended for assembly.


- Clear out the space for assembly and lay out all parts on Parts List, extra room will allow you to easily determine if all the pieces are present.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- Keep small parts and pieces away from children and pets until fully assembled.
- Please check for any loose screws and tighten them before you use.

WARNING: DO NOT LET CHILDREN PLAY IN OR AROUND THE UNIT DUE TO THE POSSIBLE RISK OF INJURY.

Parts List




(A) Top X 1



(B) Legs X 3



(C) Bolts X 12




(D) Allen Key X 1

Spare parts




(C) Bolts X 1



Step 1-- Remove all parts from the carton and place them on a protected surface or carpet.
Place the Top (A) upside down.



Step 2 -- Attach Legs (B) x3 to Top(A) then fixed by Bolts (C) x12 , Then tighten Bolts (C) x12 securely with Allen Key (D)



Step 3--



Product Dimension