


CHRISTMAS TREE



SIZE:12.8FT

User Manual

PARIS LIST

1	Parts		QTY
	A		1
	B		1
	C		5
	D		5
	E		1
	F		1

3	Parts		QTY
	a		20
	b		20
	c		20
	d		30
	e		5
	f		5

2	Parts		QTY
	G		2
	H		1
	I		1
	J		1
	K		1
	M		1

Contact Us

You can contact our customer service team via xmasshow@hotmail.com



Scan for Extended Warranty & Installation Video

1

Step 1: Assemble Base

- Using [a], [b], and [c], connect components [A], [C], and [D] to form a circular base.

2

Step 2: Position Base

- Find a flat surface and place the circular base at the desired location.
- For deep grass (over 2 ft):
 - Insert [E] through the center hole of [A]
 - Attach [M] to the top hole of [E]
 - Rotate [E] using [M] until base is fully secured
 - Fix using the [f] accessory


3

Step 3: Install Lighting

- Place light panel [J] onto [I]'s tray
- Thread [J]'s connector through internal hole
- Connect to [K]'s connector
- Attach [I] to [K]


3. For hard surfaces (e.g., concrete):

- Connect [B] to [A]
- Push [F] down over [A] until snug
- Place weights on the base edges for stability




Step 4: Prepare LED Strip

- Unwind LED strip cable
- Straighten toward end using protective cap [e]
- Retain [e] near end for later installation



Step 5: Assemble Poles

- Connect poles in sequence: [E/F] → [G] → [H] → [I]
- Ensure all joints are tight and secure



Step 6: Mount LED Strips

- Remove protective cap [e] from each LED strip
- Secure clip [d] to each strip's end
- Hook [d] into side holes of [C]

CAUTION
[d] has sharp points. Wear gloves and handle with care to avoid injuries.

PLEASE NOTE:

- 1 Ensure that the end of the line lights is securely connected to the spring hook and be cautious of the sharp tips of the spring hook to prevent the risk of scratches.
- 2 When installing the poles, verify that each pole component is securely connected to avoid the risk of falling and causing injury due to loose connections.
- 3 Please use the product in clear weather. In the event of sudden rain or snow, immediately cut off the power to prevent the risk of electric shock.

CUSTOMER SERVICE

- 1 If you have any product installatiion problems or other questions, you can contact our customer service team via **xmasshow@hotmail.com**
We will answer you as soon as possible!



Scan for Extended Warranty & Installation Video

FCC WARNING STATEMENT:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.