
FNZ24101801P1



As this item contains many parts, please read the installation instruction carefully before installation and complete the installation with the cooperation of your partner. Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

CONTACT US ANYTIME FOR TOP-NOTCH CUSTOMER SERVICE

Q: Need help with assembly?

A: We could provide detailed installation videos. Contact us for step-by-step guidance to ensure successful installation.

Q: Found damaged panels or missing accessories?

A: Let us know, and we'll promptly send replacements your way.

Q: Have feedback on product usage?


A: Contact us, and we'll collaborate to ensure the best experience for you.

DO NOT RETURN PRODUCT TO WAREHOUSE
CONTACT US BY EMAIL OR PHONE

TOLL-FREE：[+001]877-297-2788
Monday-Friday 9:00am-5:00pm | Saturday & Sunday 9:00am-12:00am

EMAIL：SERVICENOW.GDC@GMAIL.COM
Reply to email within 24 hours

Before You Start




- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. （Assembly speed can be increased by using electric screwdriver）


Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: **1-2**


- Open your item in the area you plan to keep it to avoid excessive heavy lifting.



- Identify, sort and count the parts before attempting assembly.



- Compression dowels are lightly tapped in with a hammer.




- Slides are labeled with an **R** (right) and **L** (left) for proper placement.


- Make sure to always face the point on the top of the Cam Lock towards the outer edge.



- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.



-Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.




- Do NOT use harsh chemicals or abrasive cleaners on this item.


- Never push, pull, or drag your furniture.

Board Identification


Not actual size




A
Qty:2




B
Qty:2




C
Qty:1




D
Qty:1




E
Qty:1




F
Qty:1



G
Qty:1



H
Qty:1



I
Qty:1

Part List



Ø15X9.5mm

①	X18

CAM LOCK
spare:2



Ø6.5X35mm

②	X18


CAM BOLT
spare:2



Ø8X30mm

③	X16


WOOD DOWEL
spare:2



Ø3.5X12mm

④	X24


SCREW
spare:2



Ø5X16mm

⑤	X4


SHELF SUPPORT
spare:1



Ø26mm

⑥	X4


HINGE



190X32mm

⑦	X2


HANDLE



M4X22mm

⑧	X4


HANDLE SCREWS



Ø21mm

⑨	X8


HOLE STICKER
spare:1



Ø3X14mm


⑩	X4set

BACK PANEL BUCKLE
spare:1



⑪	X1set

SCREW ANCHOR SET




70X30X5mm

⑫	X1

SCREWDRIVER


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Board Identification


Not actual size




STEP1


If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.








X2








X2


STEP2

If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.











STEP3

If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.






Ø15X9.5mm	
1	X4




When performing this step, you will need assistance from another person to stand the product upright.


90°

REVERSE






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


STEP4


If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.



Ø15X9.5mm		Ø8X30mm		Ø21mm	
1	X4	3	X6	9	X4









180°

REVERSE




Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP5


If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.






Ø15X9.5mm

1	X10




Ø8X30mm

3	X6




Ø21mm

9	X4




Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

STEP6

If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.











STEP7


If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.
















STEP8

If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.




Ø3.5X12mm		190X32mm		M4X22mm	
4	X16	7	X2	8	X4




STEP9

If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.




NOTE: If you encounter a gap or difficulty closing the door after installation, please email us at **SERVICENOW.GDC@GMAIL.COM**
We offer helpful videos.




[How to adjust vertical height of the door]

- First remove the 2 screws “A+”on the hinge.
- Then loosen the 2 screws “A”on the hinge so that it can be adjusted up or down a few millimeters.
- Then tighten "A" and reinstall "A+".



[How to adjust the level of the door]

- Turn screw "C" on hinge to adjust the level of the door.





[How to adjust depth of the door]


- Loosen screw "B" and adjust the depth of the door.
- If screw "B" is loose, the depth of the door still cannot be adjusted. Simply loosen the screw "C" slightly to adjust the position of the door forward and backward.
- After adjusting the position, tighten screw "B" last.

STEP10

If you have installation issues,please don't return the item.
Contact us at SERVICENOW.GDC@GMAIL.COM for assistance.









Insert the plastic buckle into the back plate slot,
screw through the hole in the plastic buckle and lock it in place.


STEP11

If you have installation issues,please don't return the item.
Contact us at **SERVICENOW.GDC@GMAIL.COM** for assistance.




Note:When installing the I panel, sufficient space should be reserved at the top for hanging cabinets.






STEP1

Set the hole position near the wall




STEP2

Put the embedded part into the hole



STEP3

Put the screw part into the hole



cabinet body back alignment plate I inserted

