


ITEM NO . NSCC1861

Scan for manual ,
video & advice

If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com


MAINTENANCE AND WARNINGS


Thank You For Choosing Our Furniture.
Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :
This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
80 LBS


Installation:
40 minutes.


Two Person



Before You Start

Please follow the steps below:

- Unbox the package and check if all parts and accessories are complete.
- If you find something missing, stop assembly and contact your supplier immediately.
- Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- NOTE:Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty

We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having dificulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**


For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis,or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all the parts in the box and start the installation.




Parts List

A x1




Top panel

B x1




Baseplate

C x1




Left side panel

D x1




Right side panel

E x2




Side arc plate

F x1




Back panel

G x1




Inner back panel

H x1




Rear connecting plate

I x2




Middle link bar

J x2




Left right horizontal

K x2




front and back horizontal

L x1




Small drawer left side panel

M x1




Small drawer right side panel

N x1




Drawer back panel

O x1



Small drawer bottom panel


P x1



Drawer support


Parts List

Q x1




Small drawer Front Panel

R x2




Drawer left side panel

S x2




Drawer right side panel

T x2




Drawer back panel

U x2




Drawer bottom panel

V x2



Drawer support


W x2



Large draw panel

Hardware List

1 x34+2




Bolt
Ø6*35mm

2 x34+2




Eccentric wheel
Ø15*9.5mm

3 x4+1




Roller Coaster Silk
Ø6*50mm

4 x1



Socket

5 x14+2



Screw
M3*15mm

6 x2




Screw
M3.5*12mm

7 x8+2



Screw
M4*15mm

8 x38+2



Wood plug
Ø8*30mm

9 x6




Knobs

10 x4



One character connector

11 x1



Tie

12 x2




Anti-tip
component

13 x2




Wall anchor

14 x1




Screwdriver
(Not Included)

15 x2



Screw
Ø3.5*30mm

16 x2




Screw
Ø3.5*20mm

17 x6



Bolt
5/32"*15mm

18 x1





Allen key

ASSEMBLY INSTRUCTIONS

Step 1

1.Properly insert cam bolts (1) to Part (H) and fully tighten with screwdriver (14).
2.Attach Part(G)To Part(H) insert wood plug (8) Tighten by Eccentric Wheel (2)clockwise with screwdriver (14).


1		x 2	Cam bolt Ø6*35mm
2		x 2	Eccentric wheel Ø15*9.5mm
8		x 2	Wood Plug Ø8*30mm
14		x 1	Screwdriver




Step 2

Properly insert Cam Bolts (1) to Part (C,D) and fully tighten with screwdriver (14).

1	x 8	Cam Bolt Ø6*35mm
14	x 1	Screwdriver







Step 3

Attach Part(G,H,I)To part(C) insert wood plug (8) tighten by Eccentric wheel (2)clockwise with screwdriver (14).

2	x 4	Eccentric wheel Ø15*9.5mm
8	x 3	Wood plug Ø8*30mm
14	x 1	Screwdriver






Step 4

Attach Part(D)to part(G,H,I) insert Wood plug (8) Tighten by Eccentric wheel (2) clockwise with screwdriver (14).


2	x 4	Eccentric wheel Ø15*9.5mm
8	x 3	Wood plug Ø8*30mm
14	x 1	Screwdriver




Step 5

Properly insert Cam Bolts (1) to Part (B) and fully tighten with screwdriver (14).

1	x 6	Cam bolt Ø6*35mm
14	x 1	Screwdriver






Step 6

1.Insert Wood plug (8) into the left,right side panel (C,D).

2.Pass the Direct repair screws (3) through the left,right side panel (C,D) to assemble them, and tighten them with Allen key (18)


8		x 4	Wood plug Ø8*30mm
3		x 4	Direct repair screw Ø6*50mm
18		x 1	Allen key





Step 7

1.Properly insert Cam Bolts (1) to Part (J) and fully tighten.

2.Attach Part(J)To Part(K) insert Eccentric wheel (2) into the corresponding hole of the part(K) and secure it with screwdriver (14).

1		x 8	Cam bolt Ø6*35mm
2		x 8	Eccentric wheel Ø15*9.5mm
14		x 1	Screwdriver







Step 8

Attach Part(K,J)To part(B) Insert Wood plug (8) Insert Eccentric wheel (2) into the corresponding hole of the part(J,K) and secure it with a screwdriver (14).

2	x 6	Eccentric wheel Ø15*9.5mm
8	x 4	Wood plug Ø8*30mm
14	x 1	Screwdriver








Step 9

1.Install Socket (4) to Part (H) and tighten By screw (6) with screwdriver (14) .


2.Install back panel (F) into the groove , make sure all holes aligned and use screw (5) to attach them, tighten screw (5) with screwdriver (14).


4		x 1	Socket
6		x 2	Screw Ø3.5*12mm
5		x 14	Screw Ø3*15mm
14		x 1	Screwdriver




Step 10

Properly insert Cam Bolts (1) to Side arc plate (E) and fully tighten,with screwdriver (14).
Repeat this step two more times.

1	 x 8	Cam bolt Ø6*35mm
14	 x 1	Screwdriver







Step 11

1.Properly insert Cam Bolts (1) to Part (A) and fully tighten.

2.Install Anti-tip component (12) to Part (A) and tighten By screw (16) with screwdriver (14) .

1	x 2	Cam bolt Ø6*35mm
12	x 1	Anti-tip component
16	x 2	Screw Ø3.5*20mm
14	x 1	Screwdriver







Step 12

Attach Part(E)To part(A) insert Wood plug (8) ,Insert Eccentric wheel (2) into the corresponding hole of the part(A) and secure it with a screwdriver (14).

2	x 4	Eccentric wheel Ø15*9.5mm
8	x 6	Wood plug Ø8*30mm
14	x 1	Screwdriver






Step 13


Install One character connector (10) to Part (A, E) and tighten By screw (7) with screwdriver (14) .


7	x 8	Screw M4*15mm
10	x 4	One character connector
14	x 1	Screwdriver




Step 14

1.Attach Part(A,E)To part(C,D,G) insert Wood plug (8) Insert Eccentric wheel (2) into the corresponding hole of the part(C,D,G) and secure it with a screwdriver (14).

2	 x 6	Eccentric wheel Ø15*9.5mm
8	 x 8	Wood plug Ø8*30mm
14	 x 1	Screwdriver






Step 15

1.Install panel (L,M) into panel (N), make sure all holes aligned, then flip the tabs on the back of the Drawer Back Panels (N) to lock them in place.


2.Install panel (R,S) into panel (T) insert by Wood plug (8) , make sure all holes aligned, then flip the tabs on the back of the Drawer Back Panels (N) to lock them in place.
Repeat this step two more times.


8	x 4	Wood plug Ø8*30mm



Step 16

1.Attach Drawer Support Panels (P) and slide in the drawer bottom panels (O) in to back drawer panel (N).
2.Attach Drawer Support Panels (V) and slide in the drawer bottom panels (U) in to back drawer panel (T).
Repeat this step two more times.






Step 17

1.Attach the Front Drawer Panels (Q) to the drawer sides(L,M,P), making sure the lock are aligned.


2.Attach the Front Drawer Panels (W) to the drawer sides(R,S,V), insert by Wood plug (8)making sure the lock are aligned,Repeat this step two more times.

8	x 4	Wood plug Ø8*30mm




Step 18


1.Install Hanld (9) to Part (Q) and tighten By Bolt (17) with screwdriver (14) .
2.Install Hanld (9) to Part (W) and tighten By Bolt (17) with screwdriver (14) .
  Repeat this step two more times.

17		x 6	Bolt 5/32"*15mm
9		x 6	Handle
14		x 1	Screwdriver


Step 19




Schematic diagram of slide rail disassembly




Attention：When installing the drawer,slide the steel ball slide rail of side panel to the most front as picture show.





Step 20



Attention:
Before the next step,
adjust the feet of the
locker to keep it level.










Step 21


Install Anti-tip device (12,13,15) to the wall in this step.

12		x 1	Anti-tip component
15		x 2	Ø3.5 x 30mm
13		x 2	Wall anchor
14		x 1	Screwdriver






1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device (12) to the wall with screws (15).

Step 22

WARNING




Children have died from furniture tipover.To reduce the risk of furniture tipover:


-ALWAYS install anti-tip device provided.
-NEVER put a TV on this product.
-NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.




This is a permanent label.
Do not remove!

11	x 1	Tie







WWW.HULALAHOME.COM
Email: customerservice@hulalahome.com
Call us: +1(833)324-2464(8 AM to 5 PM PST Monday-Friday)