


DS-900




Important!







Thank you for your purchase. Please open it carefully.

If you encounter any problems during assembly and use, please contact us through the Amazon email platform.


We have the ability to solve all your problems.

Service tenet - to enable customers to enjoy high-quality service.



PARTS LIST				LISTE DES PIÈCES				LISTA DE PIEZAS			
Name Nom Nombre		Part Piece Pieza	Qty Qte	Spare Epargner Sobrante	Name Nom Nombre		Part Piece Pieza	Qty Qte	Spare Epargner Sobrante		
A	side panel		2		G	door panel		1			
B	Back panel		1		L	door lock		1			
C	Top panel		1		N	Self-tapping screw 4*8		14	2		
D	divider board		3		O	Shelf support		8			
					Q	magnet		2			
E	Supporting leg		2		S	Door Pivot Pim/Shim		1			
					T	Door handle-and Screw		1			
F	leveling foot		4		V	laminate fastening buckle		8			
					W	fixing bolt		2			


1




F-4

2

Before installation, carefully confirm the hole position of (H), so that the smaller side in the distance is installed outside




3




N-4

4



N-4


5




N-6

6

The grooved side is combined with the back panel.




7







0-8

8








9




V-8

10





S-1

11





Q-2

12




T-1

13




Install the lock component with the key in a vertical position and the locking hook in a horizontal position. In this state, it is locked, and rotating clockwise by 90 ° indicates an open state.



L-1

14





suggest fixing the cabinet to the wall to prevent tipping over!



W-2

Problems and Solutions

Question 1: when encountering uneven height of two door panels, adjust the bottom adjustment foot to make it flat.



Question 2: When the door is closed, it still protrudes outward.
That's because the door is made of steel plate and has stretchability.
You can adjust it according to the method shown in the picture.

