


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY  DIFFICULT

Tools Required For Assembly:

Allen Wrench



Phillips Screwdriver




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




1
When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2
Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3
Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



4
Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5
Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




6
Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Headboard Bookcase



#2 x 1pc
Footboard



#3 x 2pcs
Side Rail



#4 x 1set
Twin Slat Kit (10pcs)

Hardware List



#A x 8pcs
Bolt $\text{\O}1/4"$ x 3-1/8"




#B x 8pcs
Barrel Nut $\text{\O}1/4"$ x 1/2"



#C x 8pcs
Screw #4 x 30mm




#D x 1pc
Allen Wrench 4mm






Insert barrel nuts (#B) to the side holes of the side rails (#3). Align side rails (#3) to the holes of the headboard (#1) and footboard (#2), then secure by tightening bolts (#A) onto barrel nuts (#B).

#A x 8pcs
#B x 8pcs




Align slats (#4) to the side rails (#3), then secure by using screws (#C).

#C x 8pcs



Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




1
When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2
Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3
Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



4
Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5
Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




6
Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.


















Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

Parts List

Hardware List




Exploded View



#C x 4pcs
#B x 4pcs
#E x 6pcs


Insert dowels (#E) to center vertical panels (#5), then align center vertical panels (#5) to the holes of the top panel (#1).




Insert dowels (#E) and barrel nuts (#B) to center vertical panels (#5), then align center vertical panels (#5) to the holes of the horizontal panel (#4). Secure by using bolts (#C).




#D x 8pcs
#E x 8pcs



Insert dowels (#E) to top and horizontal panels (#1,4), then insert dowels (#E) to horizontal bar cabinets (#6) from step 3. Align and attach side panels (#2,3) to the top, horizontal panels (#1,4) and bar cabinets (#6). Secure top and horizontal panels (#1,4) by using bolts (#D).



#A x 4pcs
#B x 4pcs
#E x 8pcs




Insert barrel nuts (#B) to horizontal bars (#6), then secure by tightening bolts (#A) to barrel nuts (#B).



#4

#G x 32pcs


Align back panel (#8) to the back of the unit, then secure by using screws (#G).




#5

#D x 4pcs
#F x 8pcs

Insert dowels (#F) to the support rails (#7), then attach support rails (#7) to unit. Secure by using bolts (#D).





#G x 4pcs

Secure both bed and shelves together by using screws (#G).

